


Controller description



ST-87x / ST-88x

Vehicle controller



Conductix-Wampfler Automation GmbH
Handelshof 16 A
14478 Potsdam
Germany
Telephone: +49 (0) 331 887344-0
Fax: +49 (0) 331 887344-19
Email: info.potsdam@conductix.com
Internet: www.conductix.com
Translation of the original
STB_0005, 7, en_GB

Table of contents

1	Information on the description.....	9
1.1	Revision history.....	9
1.2	How to use and store the description.....	9
1.3	Applicable documents.....	10
1.4	Copyright protection.....	10
1.5	Illustrations.....	10
1.6	Brands.....	10
2	Warranty and liability.....	11
2.1	Warranty.....	11
2.2	Limitation of liability.....	11
3	Safety instructions.....	13
3.1	Warning concept.....	13
3.1.1	Arrangement of warnings.....	13
3.1.2	Structure of warnings.....	13
3.1.3	Signal words.....	14
3.1.4	Hazard symbols.....	14
3.1.5	Suggestions and recommendations.....	15
3.2	Intended use.....	16
3.3	Foreseeable incorrect use.....	16
3.4	Modifications and alterations.....	16
3.5	Responsibility of the operator.....	17
3.6	Personnel and qualifications.....	18
3.7	Special hazards.....	20
3.8	Safety instructions for the system operator and manufacturer....	21
3.9	Safety devices.....	22
3.10	Safe isolation.....	23
4	Product description.....	25
4.1	Series 8.....	25
4.2	87x / 88x series model name.....	25
4.3	87x / 88x series power classes.....	25
4.4	87x / 88x series scope of functions.....	25
4.5	Type label.....	26
4.6	ST-87x / 88x designs.....	27
4.7	Basic device.....	28
5	Transport and storage.....	29
5.1	Transport.....	29

5.2	Transport inspection.....	29
5.3	Storage.....	30
6	Mechanical installation.....	31
6.1	Open spaces and cooling.....	34
6.2	Installation position.....	36
6.3	Installation.....	37
6.3.1	Installation with direct screw connection.....	39
6.3.2	Installation with attachment bracket.....	40
7	Electrical installation.....	43
7.1	Notes about electrical installation.....	46
7.1.1	Residual current circuit breaker and mains fusing.....	46
7.1.2	Electromagnetic compatibility.....	46
7.1.3	EMC installation notes.....	48
7.1.4	Cable routing.....	52
7.1.5	Control system motor output.....	52
7.1.6	Protective measures.....	53
7.2	Connecting the electrical parts of the control system.....	54
7.3	Electrical connections.....	56
7.3.1	Connection overview.....	56
7.3.2	X1 - Supply.....	57
7.3.3	X2 - Motor.....	58
7.3.4	X10 - BLDC motor encoder.....	59
7.3.5	X10 - Brake resistance.....	60
7.3.6	X13 - Sensors.....	60
7.3.7	X14 - Sensors.....	61
7.3.8	X15 - Sensors.....	62
7.3.9	X16 - Sensors.....	62
7.3.10	X17 - Sensors.....	63
7.3.11	X30 - USB.....	64
7.4	Earthing the control system.....	65
8	Commissioning.....	67
8.1	Notes about commissioning.....	70
8.2	Requirements.....	71
8.3	Commissioning procedure.....	72
8.4	Switch on control system.....	73
8.5	Assign control system parameters.....	75
8.5.1	Vehicle parameters and configuration switches.....	76

8.5.1.1	Creating and saving parameters and configuration switches.....	77
8.5.1.2	Transferring parameters and configuration switches.....	78
8.5.2	Vehicle tables – PCM system (ST-87x/ST-88x).....	80
8.5.2.1	Creating and saving vehicle tables.....	81
8.5.2.2	Transferring vehicle tables.....	81
8.5.3	Vehicle tables – rail bus SB (ST-87x-SB/ST-88x-SB).....	83
8.5.3.1	Creating and saving vehicle tables.....	84
8.5.3.2	Transferring vehicle tables.....	85
8.6	Configuring the bus communication (ST-87x-SB/ST-88x-SB).....	87
8.7	Test control system.....	88
8.7.1	Test – motor functions.....	88
8.7.2	Test – Sensors and peripherals.....	90
8.7.3	Test – Communication.....	91
8.8	Optimise settings.....	93
9	Operation.....	95
9.1	Operating modes.....	97
9.2	Switching the control system on and off.....	98
9.2.1	Switch on control system.....	98
9.2.2	Switches the control system off.....	99
9.3	Displays.....	100
9.3.1	Status LEDs.....	100
9.3.2	Display.....	102
9.3.3	Display modes.....	104
9.3.3.1	Creating/modifying display modes.....	104
9.3.3.2	Calculating and evaluating hexadecimal values.....	105
9.4	Vehicle remote control.....	107
9.4.1	Changing operating mode.....	108
9.4.2	Moving the vehicle manually.....	109
10	Faults.....	111
10.1	Displaying faults and errors.....	111
10.2	Error messages.....	112
10.3	Error codes.....	112
10.4	Fault types.....	113
10.5	Fault reset.....	114
11	Service and maintenance.....	117
11.1	Maintenance and cleaning.....	117

11.1.1	Maintenance.....	117
11.1.2	Cleaning.....	118
11.2	Removing / replacing the control system.....	118
11.2.1	Control system removal.....	119
11.2.2	Control system installation.....	120
11.3	Repairing the control system.....	120
12	Disposal.....	121
12.1	Information on disposal and environmental regulations.....	121
13	Technical specifications.....	123
13.1	Device.....	123
13.2	Input data.....	125
13.3	Output data.....	126
13.4	Interfaces.....	128
13.5	Cable lengths and specifications.....	128
13.6	Approvals and standards.....	129
14	Information and parameter assignment.....	131
14.1	Three-phase current asynchronous motor.....	131
14.1.1	Layout and function.....	131
14.1.2	How it works.....	132
14.2	Permanent magnet synchronous motor.....	135
14.2.1	Layout and function.....	135
14.2.2	How it works.....	136
14.2.3	Parameters for the settings of the controlled operation.....	138
14.2.4	Parameters for the settings of controlled operation (vector control).....	139
14.3	Brushless DC motors.....	140
14.3.1	Layout and function.....	140
14.4	Frequency converters.....	140
14.4.1	Layout and function.....	141
14.4.2	Rectifier.....	141
14.4.3	Intermediate circuit.....	141
14.4.4	Inverter.....	142
14.4.5	Control circuit.....	143
14.4.6	ST-87x/88x Current Monitor.....	143
14.4.6.1	Hardware short circuit shutdown.....	143
14.4.6.2	I ² t-monitor (maximum load integral).....	143
14.4.6.3	Software-based shutdown in the event of excess current....	145



15	Customer service and addresses.....	147
16	Index.....	149

1 Information on the description

1.1 Revision history

We reserve the right to make changes to the information present in this document, which result from our constant effort to improve our products.

Version	Date	Comment/reason for change
1	03.2018	Basic version
2	04.2018	Text corrections
3	04.2018	Text corrections
3.1	06.2021	Corrections pin configuration X1, X13, X14
4	08.2021	New chapter structure
5	05.2022	Conductix-Wampfler Automation GmbH
6	03.2023	New start display
7	04.2023	Certification updated

1.2 How to use and store the description

This documentation forms part of the product. It contains important information and notes on using the product. It affects:

- Mechanical and electrical installation
- Commissioning
- Operation
- Maintenance and service

To work safely with the product, it is necessary to observe the safety notes and action instructions. All persons working with the product must have understood the user information in this description and apply it conscientiously. The operator must fulfil his duty of care and ensure that all persons working with the product have read and understood the user information and are implementing it.

This description forms part of the product and must be accessible to all persons working with the product at all times.

1.3 Applicable documents

The documents contained in the project documentation also apply if the device / system is part of a project-specific system plan.

The following documents are considered part of this description. They are located at the end of this description or they are included as an extra description in the scope of delivery.

- Connection diagram ANS
- Device drawing GER
- Software description BV

Connected devices and components are covered by their own documentation.

Applies additionally when the vehicle control system is used in the bus master system:

- Project-specific interface description BV

1.4 Copyright protection

The contents, texts, drawings, pictures and other illustrations of this description are protected by copyright and subject to intellectual property rights. Any misuse is punishable by law.

Reproduction in whole or in part of this description is only permitted within the limits of the legal provisions of the copyright law. Any modification or shortening of the text is prohibited without the explicit written consent of Conductix-Wampfler Automation GmbH.

1.5 Illustrations

The illustrations that accompany this description have been purposely selected. They are provided for basic understanding and may differ from the actual design. No claims shall be accepted for possible discrepancies.

1.6 Brands

The popular names, trade names, production descriptions, etc. used in this description may constitute trademarks even without special designations and as such may be subject to legal requirements.

2 Warranty and liability

2.1 Warranty

The warranty only covers production defects and faulty components.

The manufacturer assumes no responsibility for damages caused during transport or unpacking. In no case and under no circumstances will the manufacturer be liable for defects or damages caused by misuse, incorrect installation or inadequate environmental conditions or from dust or corrosive substances.

Consequential damages are excluded from the warranty.

Should you have further questions regarding the warranty, please contact the supplier.

2.2 Limitation of liability

All information and notes in this description have been compiled taking into account the applicable standards and regulations, the state of the art and our many years of knowledge and experience.

Conductix-Wampfler Automation GmbH assumes no liability for damage and malfunctions during operation due to:

- Failure to comply with the description
- Non-intended use
- Use by untrained personnel
- Unauthorised alteration or modification
- Use of the product, despite negative transport inspection

Furthermore, Conductix-Wampfler Automation GmbH's warranty obligation will cease to exist in case of a failure to comply with the description.

3 Safety instructions

This section contains information on all safety aspects for optimum protection of personnel and for safe operation without malfunctions.

To prevent dangers, these notes must be read and followed by personnel. Only then can safe operation be guaranteed.

Of course, all legally applicable general safety and accident prevention regulations must be complied with.

Conductix-Wampfler Automation GmbH assumes no liability for damage or accidents that were caused by non-observance of these safety notes.

3.1 Warning concept

This description contains notes that must be observed for your own personal safety and to avoid property damage. Notes regarding your personal safety are highlighted by a warning triangle; notes regarding property damage do not have a warning triangle.

When several hazard levels occur, the warning always refers to the highest level. If a warning of injury to persons is indicated with a warning triangle, the same warning might include an additional warning of property damage.

3.1.1 Arrangement of warnings

If warnings refer to an entire section, they are placed at the beginning of the section (e.g. chapter start).







If warnings refer to a specific action instruction, they are placed in front of the respective action instruction.

3.1.2 Structure of warnings

- **SIGNAL WORD**
- ↳ Type of danger and its source
- ↳ Possible consequences, if not observed
- ↳ Danger avoidance measures
- ↳ Preventive measures

3.1.3 Signal words







Warnings are indicated using signal words based on hazard levels.

Signal word	Meaning
 	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.
 	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
 	This combination of symbol and signal word indicates a possible dangerous situation that can result in material damage if it is not avoided.

3.1.4 Hazard symbols

Warnings of the groups 'danger' and 'warning' are content-based. They are presented with clear danger symbols.

Warnings of the 'caution' group do not have a specific danger symbol.

Warning signs	Type of danger
	Warning – automatic start-up.
	Warning - danger of crushing.
	Warning – high-voltage.
	Warning – danger of falling.
	Warning – falling objects.
	Warning – hot surface.

Warning signs**Type of danger**

Warning – danger zone.

3.1.5 Suggestions and recommendations

This symbol indicates important information to help you handle the product.

3.2 Intended use

The controller has been designed and constructed exclusively for the intended use described below.

Conductix/LJU vehicle control systems are equipped with frequency converters. These controllers are intended for use in industrial and commercial systems for the operation of motors, which can be used with frequency converters.

Electrical systems or machines must comply with the EU Directive 2006/42/EC (Machinery Directive) or the DIN EN 60204-1 standard if they are to be fitted with Conductix/LJU vehicle control systems. Intended operation is only permitted in compliance with the EMC Directive (2014/30/EU EMC).

3.3 Foreseeable incorrect use

Any use that goes beyond this description is forbidden.



⚠ WARNING!

Hazard from improper use!

Any use of the controller other than and/or beyond the one intended can cause hazardous situations.

- Only use the controller as intended.
- Only connect motors that are suitable for use with frequency converters.
- Do not connect any other loads.
- It is paramount to comply with all the specifications and permitted conditions at the place of use.
- Do not use the controller in potentially explosive atmospheres.
- Do not operate the controller in environments with harmful oils, gases, vapours, dusts, radiation, etc.
- Do not use the controller for the transportation of people or animals.

3.4 Modifications and alterations

For the purpose of avoiding hazards and for ensuring optimum performance, any modifications, additions, or alterations to the controller require Conductix-Wampfler Automation GmbH's express consent.



⚠ WARNING!

Injury hazard from structural modifications!

Unauthorised technical modifications can cause substantial bodily harm or material damage.

- Replace faulty control systems.
- A faulty control system should only be replaced by an identical control system.

3.5 Responsibility of the operator

The control system is used in an industrial environment. The operator of the control system is therefore subject to statutory obligations regarding work safety.

In addition to the work safety instructions in this description, the safety, accident prevention and environmental regulations applicable to the area where the control system is used must be complied with.

The following applies in particular:

- The operator must become familiar with the applicable work safety regulations and must also determine the dangers that are posed by the particular work conditions at the location where the control system is to be used by means of a risk assessment. This must be realised in the form of operating instructions for operating the control system.
- This description must be kept within easy reach of the control system be accessible to those persons charged with working both on and with the control system at all times.
- The specifications of the description must be adhered to fully and unconditionally.
- The control system may only be operated when in a perfect and operationally safe condition. The control system must be checked for detectable defects prior to each time it is put into service.
- The system operator must ensure that the responsibilities for activities on the system are unambiguously defined and only adequately qualified personnel familiar with the operating and safety regulations are working on and with the control system.

3.6 Personnel and qualifications

The product / system belonging to this description may only be handled by personnel qualified for the respective task. This is done taking into account the descriptions associated with the particular task, especially the safety and warning information contained therein.

Due to their training and experience, qualified personnel are able to recognize risks and avoid possible hazards when dealing with this product / system.



⚠ WARNING!

Injury hazard from insufficient qualification!

Improper handling can cause substantial bodily harm or material damage.

Installation and commissioning



⚠ WARNING!

Danger posed by faulty installation and initial commissioning.

The installation and initial commissioning of the control system require trained specialist personnel with sufficient experience. Faults with the installation may lead to potentially fatal situations or considerable material damage.

- Have installation and initial commissioning performed exclusively by employees of the manufacturer or by trained personnel authorised by it.
- Works on electric components may only be carried out by qualified electricians or persons instructed and supervised by a qualified electrician in accordance with the electro-technical regulations.
- Before carrying out any kind of work on the controller, make sure it is de-energised and secured against accidental reconnection.
- Prior to commissioning, ensure that all safety equipment is installed and functioning properly.
- Prior to commissioning, ensure that parameter assignment on the control system has been performed correctly in accordance with the electrical and mechanical conditions of the system.

Electrical work



⚠ WARNING!

Electrical hazard!

Contact with live parts poses an immediate danger to life. The touching of open terminals and wires may lead to death or serious injury.

- Only qualified electricians are allowed to work on electrical system components, devices or equipment.
- De-energise system parts to work on them.
- Check the de-energised state of system parts disconnected from the mains voltage before starting to work on them.
- Do not open covers during operation.
- Call on the assistance of a second person who can actuate the EMERGENCY-STOP mechanism or the main switch in an emergency, when working on live parts.
- Some components in the system may still be live even after the system has been switched off. They are specially designated. Ensure to follow the notes on their designation when working on these components!
- Use only insulated tools to work on the electric system!

Operation and maintenance

The operation and maintenance of the control system must only be performed by trained and qualified personnel. Staff undergoing instruction and training are allowed to perform activities on and with the control system under the constant supervision of a trained and qualified individual.

3.7 Special hazards



⚠ WARNING!

Live parts

Contact with live parts poses an immediate danger to life. Damage to the insulation or individual components can be life-threatening.

- In case of damage to the insulation, turn off power supply immediately.
- Check devices and connected components regularly. Any loose connections, damaged cables and insulations as well as all damages that could pose a risk to safety must be rectified immediately. Any faulty protection against accidental contact must be repaired immediately.
- Works on electric components may only be carried out by qualified electricians or persons instructed and supervised by a qualified electrician in accordance with the electro-technical regulations.
- Before carrying out any kind of work on the control system, make sure it is de-energised and secured against accidental reconnection.
- Always use insulated tools.



⚠ WARNING!

Electrical voltage after shutdown

Some components of the vehicle controllers, especially the intermediate circuit of the frequency inverters, may still retain voltage after switching off. Work on these components may only be carried out after the intermediate circuit has discharged!

Disconnect the power supply safely:

- Disconnect system from power.
- Disconnect collectors from busbars.

Waiting time after voltage isolation: At least 10 minutes



⚠ WARNING!

Start/stop switch

The start/stop switch does not disconnect the controller from the power supply. Dangerous voltage is present.

- The control system must be disconnected from the power supply when performing work on it.

**⚠ WARNING!****Automatic start-up of the system**

Death or serious injuries!

If the vehicle control system is in automatic mode or is being switched to automatic mode, an automatic start-up of the system is to be expected at any time.

3.8 Safety instructions for the system operator and manufacturer

**⚠ WARNING!****Start/stop switch**

The start/stop switch does not disconnect the controller from the power supply. Dangerous voltage is present.

- Installation of a main switch by the system operator or system manufacturer.
- All poles of the power supply must be able to be switched off and protected against being switched on again.
- The control system must be disconnected from the power supply when performing work on it.

**⚠ WARNING!****Unsafe control functions**

Risk of crushing limbs, catching and dragging of loose items of clothing due to moving machine parts.

- Implement safe control functions within your system controller, if your security concept demands safe functions.

**⚠ WARNING!****Safely reduced speeds**

Risk of crushing limbs, catching and dragging of loose items of clothing due to moving machine parts.

- If your safety concept requires reduced speeds, implement safely reduced speeds within your system control.

**⚠ WARNING!****Safety note for system integration****Warning about falling parts**

Depending on the control by higher-level sensors, shutting down the control system causes the drive to come to an immediate standstill and the motor brake to engage.

- Take this into account when performing your risk assessment for system integration.

3.9 Safety devices

**⚠ WARNING!****Danger to life from non-functioning safety devices!**

Security devices ensure a maximum degree of safety during operation. Never override safety devices, even if they obstruct work processes. Safety can only be guaranteed if the safety devices are intact.

- Before starting work, check whether the safety devices are fully functional and connected properly to the controller.
- Report any faulty safety devices immediately.
- Bring vehicles with defective safety equipment to a standstill immediately.
- Get safety devices repaired immediately.

**Connected safety equipment**

For further detailed information about which safety devices are connected to the controller, please refer to the connection diagram of the controller.

3.10 Safe isolation

The vehicle controller meets all the requirements of EN 61800-5-1 and provides reliable isolation of electronic and power connections.

To ensure safe isolation, all connected electrical circuits must meet the requirements for safe isolation.

4 Product description

4.1 Series 8

"Series 8" refers to vehicle control systems of the eighth generation.

4.2 87x / 88x series model name

The following table explains the systematic structure of the 8-series type name:

ST-881-SB (BLDC)

Control system	Series	Type	Power class	Features	Features
ST-	8	7	0	-SB	(BLDC)
Normal infeed		8	1	Communication via rail bus	BLDC motor control
			2		
			3		

4.3 87x / 88x series power classes

87x/88x series control systems are available in the following power classes:

Power classes		ST-87x	ST-88x
0	up to 0.75 kW / 2.5 A	ST-870	ST-880
1	up to 1.5 kW / 4.2 A	ST-871	ST-881
2	up to 2.2 kW / 6.0 A	ST-872	ST-882
3	up to 3.0 kW / 8.0 A	ST-873	ST-883

Tab. 1: 87x / 88x series power classes

4.4 87x / 88x series scope of functions

87x/88x-series control systems have the following scope of functions in the basic configuration:

		ST-87x	ST-88x
Controllable axes	1	✓	✓
Converter	1	✓	✓
Connections (Quantity)	Fixed	✓	✓
Connection configuration	Parameter-controlled	✓	
	Software-controlled		✓
Supported sensors	Fixed ("standard" sensors)	✓	✓
Software	Fixed scope of functions	✓	
	Project-specific		✓
Device size / design	Fixed	✓	✓

Tab. 2: Series 8 scope of functions

4.5 Type label

The following image shows an example of a type label of an ST-870 control system.





Fig. 1: ST-870 type label

- 1 Model name
- 2 WNR item number
- 3 Serial number, year of construction
- 4 Rated input voltage, rated input frequency, rated input current
- 5 Output voltage, output frequency, rated motor power
- 6 Protection type, protection class, short-circuit current
- 7 QR-Code (serial number)
- 8 CE marking
- 9 NRTL marking for NRTL-approved control systems

4.6 ST-87x / 88x designs

ST-87x / 88x-type control systems are split into power classes in three designs. The heat sinks and the external braking resistor are characteristic.

No heat sink is necessary in the power classes 0 to 1. ST-873 and 883-type control systems are fitted with retaining brackets at the factory.



Tab. 3: ST-87x / 88x designs

4.7 Basic device

The following figure shows the most important parts of the control system.




Fig. 2: ST-87x basic device

- 1 Mounting bracket (ST-873, -883)
- 2 Motor port
- 3 External brake resistor port (ST-872, -873, -882, -883)
- 3 BLDC motor monitoring port (ST-870, -871, -880, -881)
- 4 Sensor/component port
- 5 Start/stop switch
- 6 Display
- 7 Infra-red sensor/receiver
- 8 Heat sink (ST-872, -873, -882, -883)
- 9 External brake resistor (ST-872, -873, -882, -883)
- 10 Supply and data exchange port

5 Transport and storage

5.1 Transport



NOTICE!

Transport

Incorrect or improper transport may cause damage to the device.

- Only trained personnel are allowed to transport the device.
- If necessary, use suitable transport aids.
- Transport the devices with utmost care.
- Observe the symbols on the packaging.
- Do not remove packaging and transport securing devices until you are ready to start with the installation.

5.2 Transport inspection

Check the delivery for completeness and transport damage upon receipt.

Proceed as follows in case of any apparent damage:

- Refuse to accept the delivery or accept it only conditionally. Take note of the extent of the damage and write it down on the carrier's transport documents or delivery note.
- Initiate a complaints process and report the incident to the supplier. If Conductix-Wampfler Automation is your direct supplier you will find our contact information in this document.
↳ *Chapter 'Customer service and addresses' on page 147*



Claims for damages

Claim any defect as soon as it becomes apparent. Damages can only be claimed within the applicable claim periods.

5.3 Storage



NOTICE!

Storage

Incorrect or improper storage may cause damage to the device.

- Cover connections with protective caps during storage.
- Avoid mechanical stress and vibrations.
- Store in a dry and dust-free location.
- Regularly check the condition of the stored device.
- Keep environmental conditions as specified in the technical information.
- Keep the storage temperature as specified in the technical information.



NOTICE!

Storing control systems without supply voltage

Connect devices to power supply for 5 minutes after max. 2 years of standstill.

6 Mechanical installation

Objective	This section provides details on the mechanical installation. Electrical installation is possible following successful mechanical installation.
Responsible party	<p>The system integrator (e.g. system builder, operator) is responsible for trouble-free and safe installation. As the contact person, he responds to all the fitter's queries regarding safe-to-use equipment; e.g.:</p> <ul style="list-style-type: none">■ Fire protection■ Electrical equipment■ Ladders and scaffolding■ Requirements for assembly tools■ Lifting and transportation
Required personnel	<p>Due to their training and experience, only qualified and appropriately instructed personnel are able to correctly assess the respective initial situation, identify risks and avoid hazards.</p> <p>Personnel required for installation:</p> <ul style="list-style-type: none">■ Adequately qualified fitter
Required personal protective equipment	<p>The person responsible must ensure that the personnel under his responsibility are wearing the required personal protective equipment. The required personal protective equipment satisfies the requirements for the work to be carried out and all the requirements demanded by the scope of work.</p> <p>Personal protective equipment that fulfils its intended purpose:</p> <ul style="list-style-type: none">■ protects its wearer from injury;■ reduces the seriousness and severity of potential injuries. <p>Wear:</p> <ul style="list-style-type: none">■ Work protection clothing■ Safety shoes■ Protective gloves■ Protective goggles
Safety in the work area	<ul style="list-style-type: none">■ Note the safety signs in the area around the system.■ Pay attention to the safety notes in additional applicable documentation (supplier documents).

**Work safety**

Pay attention to company and task-specific work safety regulations, as well as the country-specific legal and safety regulations applicable at the location of use.

**Wear additional protective equipment**

As an employee, you wear protective equipment supplied by the area supervisor. If work tasks have been delegated only temporarily, then you also wear any protective equipment that has become additionally required.

Special hazards**⚠ WARNING!****Live parts**

Contact with live parts poses an immediate danger to life.

- Disconnect the system from the power supply before installing the mechanical and electrical parts of the control system.

**⚠ WARNING!****Danger of falling**

Danger of falling if the control system is mounted on typical assembly sites of a monorail.

- Provide safe ascent for all activities on the control system.
- Always use certified climbing aids.

**⚠ WARNING!****Falling loads**

Risk of fatality due to falling objects

- Do not stand under loads.
- Seal off areas of mechanical installation.
- Seal off danger areas.

6.1 Open spaces and cooling

87x / 88x-type control systems reach an operating temperature of approx. 70°C in load operations. In order to ensure the air circulation for cooling the control system, one must ensure sufficient open space around the control system.




Fig. 3: Open spaces around the control system (mm)



⚠ CAUTION!

Hot surfaces

Risk of burns posed by hot surfaces of the control system and connected components.

- Install protective equipment and check it regularly.
- Prior to working on the control system, allow the connected components to cool down.



⚠ WARNING!

Risk of fire due to hot surfaces

Highly flammable materials may catch fire if they come in direct or indirect contact with the hot surfaces of the device.

- Ensure that the air around the device is constantly circulated.
- Do not place any flammable materials on top of the device.
- Keep flammable materials away from the housing surface and the heat sink.



Automatic shutdown

*If the temperature of the converter or the heat sink of the control system reaches **80 °C**, the converter is shut down automatically.*

A fault message is output. Once the control system has cooled down, the fault can be acknowledged. The control system is then ready for operation once again.



Preventing heat sources

Prevent sources of heat in the immediate vicinity of the control system.

Assembly of control systems without heat sinks

When installing the control systems one must ensure unobstructed heat dissipation through the device's rear side. Adequate convection is to be ensured through a large-surface-area connection on a heat-dissipating bearing or by means of adequate air circulation.

Assembly of control systems with heat sinks

When installing control systems with heat sinks adequate circulation through the ambient air must be ensured.




Fig. 4: Circulation through ambient air

6.2 Installation position

Installation in vertical position is prescribed (type label below).




Fig. 5: Installation position

The following points must be noted when installing the control system:

- Legibility of the display
- Visibility of the status diodes
- Angle of incidence of the infra-red receiver
- Accessibility of the start/stop switch
- Ports accessible at all times




Fig. 6: Angle of incidence of the infra-red receiver (optical field of vision)

Data	Value	Unit
Incidence angle	48	°
Control system infra-red transmission range	1	m

6.3 Installation



NOTICE!

Collisions

Damage to system components

- Choose the position of the control system so that collisions with system components are excluded.



NOTICE!

Dampen impacts and vibrations

If the device is subjected to impermissible heavy impacts or vibrations, the amplitude and acceleration must be attenuated by means of appropriate measures.

- Use vibration-damping and vibration-eliminating systems.



General notes on installation and control systems

- *The control system may only be attached to the provided attachment points.*
- *Only attach the control system to the vehicle with suitable brackets.*
- *Use screw locks.*
- *The control system's switches must be accessible at all times.*
- *Display elements must not be covered.*
- *Do not cover cooling elements.*
- *Only connect external components to the control system according to the connection diagram.*
- *Secure plug connectors with safety devices (brackets, screw caps) against accidental loosening.*
- *Do not connect tensioned cables to the control system. Use strain relief devices.*

Place of installation

The vehicle control is intended for direct installation on the material-handling vehicle.

ST-87x / ST-88x attachment points

The 87x and 88x-type attachment points are located on the rear of the device.




Fig. 7: Attachment points

ST-87x / ST-88x dimensional drawing




Fig. 8: Dimensional drawing



Alternative attachment points

If the attachment points do not match those of the carrier unit, then other adapters are available for fixing upon request.

6.3.1 Installation with direct screw connection

870, 871, 880 and 881-type controllers without heat sinks are installed at the attachment points of the device's rear side.

Type 872 and 882 controllers with heat sinks can be attached to the attachment points of the device's rear side or with retaining brackets (optional).




Fig. 9: Attachment points

Data	Value	Unit
Thread	M6	
Min. screw depth	6	mm
Max. screw depth	7	mm
Tightening torque	2	Nm



NOTICE!

Threaded hole damage

Exceeding the maximum tightening torque leads to damage to the thread.

- Only tighten screw connections with the specified tightening torque.

6.3.2 Installation with attachment bracket

Type 873 and 883 control systems with a heat sink are installed with attachment brackets.

The attachment brackets are pre-assembled on type 873 and 883 control systems.




Fig. 10: Attachment bracket

- 1 Attachment bracket
- 2 Schnorr anti-vibration washer
- 3 Cylinder screw

Data	Value	Unit
Tightening torque	2	Nm



NOTICE!

Threaded hole damage

Exceeding the maximum tightening torque leads to damage to the thread.

- Only tighten screw connections with the specified tightening torque.

Attachment bracket dims




Fig. 11: Standard attachment bracket dims (mm)



Alternative attachment points

If the attachment points do not match those of the carrier unit, then other adapters are available for fixing upon request.

7 Electrical installation

Objective	This section provides details on the electrical installation. Commissioning is possible following successful electrical installation.
Responsible party	<p>The system integrator (e.g. system builder, operator) is responsible for trouble-free and safe electrical installation. As the contact person, he responds to all the fitter's queries regarding safe-to-use equipment; e.g.:</p> <ul style="list-style-type: none">■ Fire protection■ Electrical equipment■ Ladders and scaffolding■ Requirements for assembly tools
Required personnel	<p>Due to their training and experience, only qualified and appropriately instructed personnel are able to correctly assess the respective initial situation, identify risks and avoid hazards.</p> <p>Personnel required for electrical installation:</p> <ul style="list-style-type: none">■ Qualified electrician■ Adequately qualified fitter under the direction and supervision of a qualified electrician
Required personal protective equipment	<p>The person responsible must ensure that the personnel under his responsibility are wearing the required personal protective equipment. The required personal protective equipment satisfies the requirements for the work to be carried out and all the requirements demanded by the scope of work.</p> <p>Personal protective equipment that fulfils its intended purpose:</p> <ul style="list-style-type: none">■ protects its wearer from injury;■ reduces the seriousness and severity of potential injuries. <p>Wear:</p> <ul style="list-style-type: none">■ Work protection clothing■ Safety shoes■ Protective gloves■ Protective goggles
Safety in the work area	<ul style="list-style-type: none">■ Note the safety signs in the area around the system.■ Pay attention to the safety notes in additional applicable documentation (supplier documents).

**Work safety**

Pay attention to company and task-specific work safety regulations, as well as the country-specific legal and safety regulations applicable at the location of use.

**Wear additional protective equipment**

As an employee, you wear protective equipment supplied by the area supervisor. If work tasks have been delegated only temporarily, then you also wear any protective equipment that has become additionally required.

Special hazards**⚠ WARNING!****Live parts**

Contact with live parts poses an immediate danger to life.

- Disconnect the system from the power supply before installing the mechanical and electrical parts of the control system.

**⚠ WARNING!****Electric shock due to faulty PE connection or potential equalisation**

Risk of fatality posed by electric shock!

The vehicle control system must be earthed.

- Connect the PE connection on the rear side of the device to the system PE in accordance with EN 60204-1.

**⚠ WARNING!****Start/stop switch**

The start/stop switch does not disconnect the controller from the power supply. Dangerous voltage is present.

- The control system must be disconnected from the power supply when performing work on it.

**⚠ WARNING!****Danger of falling**

Danger of falling if the control system is mounted on typical assembly sites of a monorail.

- Provide safe ascent for all activities on the control system.
- Always use certified climbing aids.

7.1 Notes about electrical installation

7.1.1 Residual current circuit breaker and mains fusing



Residual current circuit breakers react very quickly, which may lead to the control system stopping frequently. Conductix-Wampfler Automation GmbH recommends not using them.



⚠ WARNING!

**Electric shock due to incorrect residual current circuit breaker
The control system may cause direct current in the protective conductor.**

Risk of fatality posed by electric shock!

- Install fuses at the start of the mains cabling.
- Install fuses behind the busbar junction.

Residual current circuit breaker (RCCD)

If the use of a residual current circuit breaker (RCCD) is prescribed for contact protection, only these types may be used on the power supply side of the frequency converter:

- Residual current circuit breaker (RCCD) type B
- Residual current circuit breaker (sensitive to universal current)

Mains-type fuse

The system must be fused on the mains side for safe operation. For mains-related protection, only use the following types of fuses:

Fuse links for cables and line protection - Operating categories: gL, gG

- Rated mains voltage \leq Rated fuse voltage
- Configure rated fuse current in line with the capacity of the frequency converter to 100% of the frequency converter current.

Circuit breakers - B, C

- Rated mains voltage \leq Rated circuit breaker voltage
- Rated circuit breaker current 10 % above frequency converter current

7.1.2 Electromagnetic compatibility

Reliable operation of frequency converters and components in the surroundings requires an electromagnetic compatibility (EMC) plan.

Generation of electromagnetic interference



The power circuit of the converter consists of the following components:

3-phase line filter

- Protects the device from external interference on the mains voltage.
- Keeps the interference of the pulse inverter away from the mains network and dissipates common-mode interference to the housing.

⚠ WARNING!

Leakage currents above 3.5 mA

Risk of fatality posed by electric shock!

- Establish safe PE connection
- The protective earthing (PE) must meet the requirements for systems with high leakage currents.

B6 rectifier

- Rectifies the 3-phase mains voltage.

Intermediate voltage circuit

- Smooths the DC voltage for the inverter.
- Keeps the differential-mode interference of the inverter away from the mains network.

IGBT pulse inverter

- The motor phase voltages are periodically switched between the positive and negative intermediate circuit voltage with the switch frequency of the inverter (usually 16 kHz).
- Voltage pulses (PWM) of varying lengths result. Motor inductances form sinus-like currents from this.



⚠ WARNING!

High charging/discharging currents

Risk of fatality posed by electric shock!

High charging/discharge currents caused by parasitic capacitances (motor winding to the housing and motor cable) have interference frequency portions up to the MHz range.

Without effective high-frequency potential equalisation, peak voltages of a few hundred volts may occur between converter and motor, which constitute significant danger.

- It is imperative you pay attention to EMC installation notes!
 ↳ Chapter 'EMC installation notes' on page 48



Voltage distortions due to harmonics

The control system is interference-suppressed for industrial applications as per EN61800-3.

The capacitive intermediate circuit in the device generates low-frequency harmonic currents on the mains side. These can lead to voltage distortions in operation on low-power networks.

Measures for reducing voltage distortions are only possible at the end of infeed point of the system.

7.1.3 EMC installation notes

EMC-compliant installation

To comply with EMC directive 2014/30/EU, the EMC product standard DIN EN61800-3 (adjustable speed electrical power drive systems; EMC requirements including special testing processes) applies to frequency converters.

The vehicle control systems are designed for use on industrial networks (second environment; PDS category 2) and appropriate interference-suppressed by means of an integrated line filter. Use in a residential environment may require additional interference-suppression measures against high-frequency interference.

EMC requirements are only met in conjunction with an EMC-compliant installation. The effectiveness of the EMC measures requires professional implementation. Even minor deviations from installation specifications could totally nullify their effectiveness.

Cables

Only use shielded motor cables with external shielding made from copper braiding.

Cables for brake and temperature sensor must each have their own inner shielding. (E.g. Ölflex Servo 719 CY or Ölflex Servo 796 CP from Lapp-kabel (Fig. 12))




Fig. 12: Shielded motor cable

- 1 Brake cable shield
- 2 Brake cable (2X)
- 3 Motor feed cable, PE (1X)
- 4 Motor feed cable, phase (3X)
- 5 Temperature sensor cable shield
- 6 Temperature sensor cable (2X)
- 7 External shield
- 8 Outer jacket

Connections

Prevent motor cable interruptions caused by additional plug connections (motor connectors or intermediate connectors). Each connector possesses additional contact resistances, thus deteriorating the high-frequency potential equalisation.

Connect outer shield of the motor cable on the motor cable connector at the control system and at the motor to an EMC cable screw connection.

Connect copper braiding across the entire cable length.



In the case of motors with terminal boxes, note that the terminal box is metallic and is conductively connected to the motor housing over a large surface area.

Only connect inner shields for the brake and temperature sensor cables on the motor connector on the control system. Fold shielded stranded wire outwards and connect with the outer shield in the metallic EMC cable screw connection.

In the case of control systems with encoder connections, only connect the shield of the encoder cable to the M12 connector on the control system, and only use cables with wires twisted in pairs.

Only connect external components with digital interfaces (position readers, distance measurers, etc.) to the control system using shielded cables.

In the case of pre-assembled shielded M12 cables, the shield is connected on both sides. The external components are usually installed so as to be insulated from the housing.

NOTICE!



If the connector is connected of an external component connected to the housing so as to be conductive, it must be installed in insulated fashion.



Fig. 13: EMC screw connection ¹

¹ Type SKINTOP MS-SC-M from Lappkabel


Cable routing

Prevent narrow, parallel routing of power and sensitive (unshielded) signal cables, especially over long distances.


Only cross cables at right angles if possible.

Prevent spare loops in all connection cables

Route motor cables over the shortest possible distances closely to the structural parts of the suspension gear or at the edges of metallic cable ducts to minimise noise emissions.



⊗ Not recommended



⊙ Recommended



Free-floating cables

Free-floating cables work as active and passive antennae!

Earth

Unused cables must be earthed at both ends.

Earth the control system and the motor on the vehicle. Connect all moving parts of the vehicle to one another so as to be electrically conductive.

Ensure large-surface-area connections of excellent conductivity for all earthing and shielding connections.

Painted parts require additional measures for paint-free contact areas, such as threaded holes for screw connections, special washers (for penetrating the paint coating) or the removal of coats of paint.

For earthing connections of moving components (e.g. control systems on painted parts or vibration dampers, parts of the suspension gear), use copper-braided strips for high-frequency potential equalisation.

Place copper-braided strips as short and close as possible onto metal parts for optimum effect.



⚠ WARNING!

Leakage currents above 3.5 mA

Risk of fatality posed by electric shock!

- Establish safe PE connection
- The protective earthing (PE) must meet the requirements for systems with high leakage currents.



NOTICE!

PE connections across single conductors

PE connections across single conductors enable potential equalisation only for low-frequency currents and can discharge residual currents. They therefore meet the safety requirements.

Single conductors are not effective for high-frequency potential equalisation.



Interference caused by motor cable

The interference caused by the wires in the motor cable cancel each other out in that the interference currents flow back to the control system through the outer shield whereby the magnetic fields outside the motor cable cancel each other out and no noise emissions are generated.

7.1.4 Cable routing

Please note with respect to cable routing:

- Use appropriate cables.
- Route cables for power and data separately.
- Maintain a distance between power and data cables.
- Avoid parallel-running cables over long distances.



maximum cable length between control system and motor(s)

- 3 m

7.1.5 Control system motor output

A capacitive load must not be present at the motor output. Only ohmic/ inductive loads may be connected.



NOTICE!

Capacitive loads

Damage to the controller

The vehicle control systems are only suitable for operating motors (ohmic-inductive loads).

- Observe permissible motor sizes and cable lengths.
- Do not connect any capacities. Capacitive loads increase switching losses and may destroy transistors.

7.1.6 Protective measures



⚠ WARNING!

Protective earthing in mobile systems

Risk of fatality posed by electric shock!

In mobile systems with direct grid feed-in, all electrical components must have a properly connected PE connection for protective grounding through the grid feed.

Overhead monorail direct grid feed

Protective earthing (PE connection) in overhead monorail applications is ensured by two consumers independent of one another on the contact line.

- Control system contact line PE connection
- Vehicle frame contact line PE connection




Fig. 14: Direct grid feed (diagram)

- 1 Overhead monorail rail with PE conductor
- 2 Overhead monorail vehicle
- 3 Vehicle control system
- 4 Motors
- 5 Vehicle earth

7.2 Connecting the electrical parts of the control system

NOTICE!



Note control system type

Operating a control system on an incorrect command system leads to serious damage and to control system failure.

- Only connect control system with PCM configuration to PCM systems.
- Only connect control system with bus configuration to bus systems.
- Check the control system configuration prior to connection and commissioning.
- Model name of the control system must match the configuration of the communication version.

NOTICE!



Malfunctions due to improper device connection

Improper device connection may lead to malfunctions during operation.

Follow the connection instructions below!

Make connections to the busbars and external components as follows:

1. ➤ Ensure that no voltage is present before connecting.
 - Switch off the vehicle control system.
 - Disconnect all busbars from the power supply and secure them against being switched on again.
2. ➤ Connect the current collectors and external components.
 - Only connect the current collectors and external components to the vehicle control system according to the [ANS] connection diagram.
 - To ensure that the protection class is achieved, only use the supplied plugs and threaded M12 plug connectors.
 - Secure plug connections against accidental loosening by means of appropriate safeguards (brackets, screw caps).
 - Do not connect cables to the vehicle control system under tension. Use strain reliefs.

**Connection diagram**

Observe the [ANS] connection diagram supplied with your control system.

7.3 Electrical connections



Note!


This chapter describes the standard connections of an ST-87x/ST-88x controller.

Connections and pin assignment may differ!

Be sure to observe the supplied device drawing [GER] and the supplied connection diagram [ANS] for your vehicle controller!

7.3.1 Connection overview

ST-87x / 88x connections



Connection		Designation	Use	
X1		Supply	Power supply	
			Rail bus	With bus system
			PCM / HW	With PCM system
			Z-stop	With Z-stop system
X2		Motor	<ul style="list-style-type: none"> ■ Motor ■ Brake ■ Temperature sensor 	
X10	ST-870 / ST-871 ST-880 / ST-881	Encoder	<ul style="list-style-type: none"> ■ Encoder ■ Thermal protection 	For PMS/BLDC motor
	ST-872 / ST-873 ST-882 / ST-883	Brake resistor	External brake resistor	
X13 X14 X15 X16 X17		Sensors	<ul style="list-style-type: none"> ■ Sensors ■ LJU bus nodes ■ etc. 	

Connection	Designation	Use
X30	USB	DataCom-Stick DCS-8

Tab. 4: ST-87x / 88x connection

7.3.2 X1 - Supply



⚠ WARNING!

Live connections

Risk of fatality posed by electric shock!

FASTON connection

- Use secure, insulated blade receptacles.
- Use blade receptacles as per standards DIN 46 245 part 3 or DIN 46 247 part 3 or DIN 46 346 part 3.
- Use insulating housing specified by the manufacturer.
- Check firm fitting and latching function.
- Replace blade receptacles without latching function.

Function	Connection type	Connection image
Supply	FASTON	
	6.3 mm	
	8-pole	

Configuration	Rail bus	PCM / HW / Z-stop
Pin	Signal	Signal
L1	Phase L1	Phase L1
L2	Phase L2	Phase L2
L3	Phase L3	Phase L3
PE	PE	PE
S1	<i>Unassigned</i>	S1 commands
S2	<i>Unassigned</i>	M messages
S3	SB_A	Z1 Z-stop

Configuration	Rail bus	PCM / HW / Z-stop
Pin	Signal	Signal
S4	SB_B	Z2 Z-stop

Tab. 5: X1 pin assignment



- Protect blade terminal contact from contact with water or other corrosive substances.
- Cover unused contacts.

7.3.3 X2 - Motor



NOTICE!

Motors with integrated brake rectifiers

Damage to or malfunctions of the drive unit when connection motors with integrated brake rectifier.

- Use motors without brake rectifier.
- Remove brake rectifiers subsequently.

Function	Connection type	Connection image
Motor	Harting	
	HAN10B	
	HAN10E use	

Configuration

Pin	Signal	Function
1	U	
2	V	
3	W	
4	Unassigned	
5	Unassigned	
6	B1 +	Brake

Configuration

Pin	Signal	Function
7	B2 -	Brake
8	B1 +	Brake *
9	PTC T +	Motor temperature sensor
10	PTC T -	Motor temperature sensor

* Connected with pin 6 via internal bridge.

Tab. 6: X2 pin assignment



Motor cable at X2

- Cable specification: multi-core, shielded, max. 3 m.
- Shield wires for thermistor and brake control within the cable separately.
- Connect outer shield to PE of control system and motor.
- Only connect the shielding for thermal resistor and brake controller to the PE of the controller.

7.3.4 X10 - BLDC motor encoder

Function	Connection type	Connection image
BLDC motor encoder	M12 socket	
	8-pole	
	A-coded	

Configuration

Pin	Signal	Function
1	+ 5 V DC	Supply
2	GND	Thermal protection
3	GLK	Encoder
4	DO	Encoder
5	/CS	Encoder
6	KTY	Thermal protection
7	Switch	Brake monitoring


STB_0005, 7, en_GB

Configuration

Pin	Signal	Function
8	+ 5 V DC	Brake monitoring

Tab. 7: X10 BLDC motor pin assignment

7.3.5 X10 - Brake resistance


Function	Connection type	Connection image
Brake resistor	M12 socket	
	4-pole	
	D coded	

Configuration

Pin	Signal	Function
1	B+	Brake resistor voltage
2	<i>Unassigned</i>	
3	B-	Brake resistor voltage
4	<i>Unassigned</i>	

Tab. 8: X10 pin assignment

7.3.6 X13 - Sensors

Function	Connection type	Connection image
Sensors	M12 socket	
	5-pole	
	A-coded	

Configuration


Pin	Signal	Function
1	+ 24 V DC	Supply
2	<i>Do not use</i>	

Configuration

Pin	Signal	Function
3	GND	
4	+ 24 V DC	Digital IN
5	<i>Unassigned</i>	

Tab. 9: X13 pin assignment

7.3.7 X14 - Sensors

Function	Connection type	Connection image
Sensors	M12 socket	
	5-pole	
	A-coded	

24 V configuration assignment

Pin	Signal	Function
1	+ 24 V DC	Supply
2	+ 24 V DC	Digital IN
3	GND	
4	+ 24 V DC	Digital IN
5	+ 24 V DC	Digital IN


5 V configuration assignment

Pin	Signal	Function
1	+ 24 V DC	Supply
2	+ 5 V DC	Digital IN
3	GND	
4	+ 5 V DC	Digital IN
5	<i>Do not use</i>	

Tab. 10: X14 pin assignment

STB_0005, 7, en_GB

7.3.8 X15 - Sensors


Function	Connection type	Connection image
Sensors	M12 socket	
	5-pole	
	A-coded	

Configuration

Pin	Signal	Function
1	+ 24 V DC	Supply
2	+ 24 V DC	Digital IN
3	GND	
4	+ 24 V DC	Digital IN
5	<i>Unassigned</i>	

Tab. 11: X15 pin assignment

7.3.9 X16 - Sensors

Function	Connection type	Connection image
Sensors	M12 socket	
	5-pole	
	A-coded	

Assignment for configuration for digital IN

Pin	Signal	Function
1	+ 24 V DC	Supply
2	+ 24 V DC	Digital IN
3	GND	
4	+ 24 V DC	Digital IN
5	<i>Unassigned</i>	

Alternatively: Assignment for configuration for LJU bus

Pin	Signal	Function
1	+ 24 V DC	Supply
2	Data_A	LJU bus
3	GND	
4	Data_B	LJU bus
5	Unassigned	

Tab. 12: X16 pin assignment



Data line at X16

If the X16 connection is configured as an LJU bus connection, shielded connection lines must be used.

7.3.10 X17 - Sensors

Function	Connection type	Connection image
Sensors	M12 socket	
	5-pole	
	A-coded	

Configuration

Pin	Signal	Function
1	+ 24 V DC	Supply
2	+ 24 V DC	Digital OUT
3	GND	
4	+ 24 V DC	Digital IN
5	+ 24 V DC	Digital OUT

Tab. 13: X17 pin assignment

NOTICE!**Excessive total current of external consumers**

The total current of all external 24 V consumers at the digital outputs and the RS485 interface must not exceed 1.0 A.

7.3.11 X30 - USB

Function	Connection type	Connection image
USB	M12 socket	
	5-pole	
	B-coded	

Configuration

Pin	Signal	Function
1	+ 5 V DC	
2	USB_data -	
3	GND	
4	USB_data +	
5	<i>Unassigned</i>	

Tab. 14: X30 pin assignment

NOTICE!**USB connection**

Connecting unapproved devices may lead to damage to the control system or the connected device.

- Only connect devices approved by Conductix-Wampfler Automation GmbH to the USB port.

7.4 Earthing the control system

The vehicle controller must be earthed for proper operation. To do this, connect the PE connection on the rear side of the device to the system PE in accordance with EN 60204-1.

The PE connection is indicated by the symbol for protective grounding. ⊕




Fig. 15: ST-87x/88x PE connection

Threaded hole	M6, 8 mm deep
Tightening torque	4 Nm max.
Cable type	Earth wire or braided copper strip
Conductor cross section	$\geq 2.5 \text{ mm}^2$ (AWG 14) Like the wire cross section of L1, L2, L3 at a minimum!

Tab. 15: ST-87x / 88x PE connection

8 Commissioning

Objective	This section provides details on correct commissioning. Daily operation can start following successful commissioning.
Responsible party	<p>The system integrator (e.g. system builder, operator) is responsible for trouble-free and safe commissioning. As the contact person, he responds to all the commissioner's queries regarding safe-to-use equipment; e.g.:</p> <ul style="list-style-type: none">■ Fire protection■ Electrical equipment■ Ladders and scaffolding
Required personnel	<p>Due to their training and experience, only qualified and appropriately instructed personnel are able to correctly assess the respective initial situation, identify risks and avoid hazards.</p> <p>Personnel required for commissioning:</p> <ul style="list-style-type: none">■ Staff of Conductix-Wampfler Automation GmbH■ Sufficiently trained specialist personnel
Required personal protective equipment	<p>The person responsible must ensure that the personnel under his responsibility are wearing the required personal protective equipment. The required personal protective equipment satisfies the requirements for the work to be carried out and all the requirements demanded by the scope of work.</p> <p>Personal protective equipment that fulfils its intended purpose:</p> <ul style="list-style-type: none">■ protects its wearer from injury;■ reduces the seriousness and severity of potential injuries. <p>Wear:</p> <ul style="list-style-type: none">■ Work protection clothing■ Safety shoes■ Protective gloves■ Protective goggles
Safety in the work area	<ul style="list-style-type: none">■ Note the safety signs in the area around the system.■ Pay attention to the safety notes in additional applicable documentation (supplier documents).



Work safety

Pay attention to company and task-specific work safety regulations, as well as the country-specific legal and safety regulations applicable at the location of use.



Wear additional protective equipment

As an employee, you wear protective equipment supplied by the area supervisor. If work tasks have been delegated only temporarily, then you also wear any protective equipment that has become additionally required.

Special hazards



⚠ WARNING!

Open connections

Contact with live parts poses an immediate danger to life.

- Work on open connections only by trained personnel.
- Do not put control system into service with open connections.
- Take protective measures against accidental contact with open connections.



⚠ WARNING!

Missing protective coverings

Risk of fatality posed by electric shock!

- Install missing protective coverings in compliance with regulations.
- Replace damaged protective coverings.
- Do not put control system into operation without protective coverings.

**⚠ WARNING!****Ineffective emergency stop**

Danger posed by uncontrolled device behaviour when the emergency-stop function is ineffective.

- Installation and commissioning only by trained personnel.
- Commissioning only with functioning emergency-stop equipment.

**⚠ WARNING!****Incorrect device settings**

Device malfunctions due to incorrect configuration.

Death or serious injuries could result.

- Installation and commissioning only by trained personnel.
- Check device settings.

**⚠ WARNING!****Impact and crushing due to motor (suddenly) starting up.**

Risk of crushing limbs, catching and dragging of loose items of clothing due to moving machine parts.

- Ensure that there are no people in the work area of powered parts before activating the control system.
- Instructions for initial commissioning for testing the connected sensors and the input parameters / training of personnel.
- Keep clear of moving system parts.
- Do not reach into the running machine.
- Wear tight-fitting work clothes.
- Pay attention to optical and acoustic warning equipment.



⚠ WARNING!

Danger of falling

Danger of falling if the control system is mounted on typical assembly sites of a monorail.

- Provide safe ascent for all activities on the control system.
- Always use certified climbing aids.



NOTICE!

Danger posed by electric arcs

Damage to electrical components.

- Pull cable connections when they are not voltage.
- Only connect cable connections when they are de-energised.

8.1 Notes about commissioning



Transfer of risk

The transfer of risk occurs when the operating parameters are entered and the operating parameters are transferred to the vehicle control system.

Pre-set parameter values

The vehicle control system is supplied without valid parameters. This status is indicated by the message **[FDA0]** on the display of the vehicle control system (following activation).

The correct functioning of the control system is only ensured once the operating parameters based on the mechanical and electrical conditions of the system have been entered.



NOTICE!

Pre-set parameter values

Control systems are subjected to testing by Conductix-Wampfler Automation GmbH before delivery. In this process, the software is installed and test parameters are set.

The pre-set parameter values are **not customer-specific** and may differ considerably from system-specific parameter values.

8.2 Requirements

Requirements for commissioning the control system:

- Correct mechanical installation
- Correct electrical installation
- System and drives fit the agreed project specifications
- Safety precautions have been taken so that no danger is posed to man or machine.
- Drive units are secured against unintended start-up by means of suitable safety measures.
- Manual programming device MU-705 (operating instructions)
- Manual remote control FB-606 (operating instructions)
- Software description for the control system
- Software description of the bus master (if used)
- Technical details for the drive and the mechanics (e.g. wheel diameter, gear ratio, etc.)

Motor data

Before parameter assignment, take the following details from the type label or data sheet of the connected motor.

Specification	Unit	For configuring the following parameters:	
Rated current	A	[In_]	Rated motor current
Nominal voltage	V	[Un_]	Rated motor voltage
Cos ϕ (motor efficiency)		[Cph_]	Motor cosine phi
Rated speed	rpm	[Rot_]	Rated motor speed
Gear ratio		[Tra_]	Motor gear ratio

8.3 Commissioning procedure

- (1) **Switch on control system**
 - ↳ Chapter 'Switch on control system' on page 73

- (2) **Assign control system parameters**
 - ↳ Chapter 'Assign control system parameters' on page 75
 - Edit vehicle parameters and configuration switches and transfer them to the vehicle control system.
 - Process vehicle tables and transfer to vehicle control system.

- (3) **Configure the bus communication (ST-87x-SB/ST-88x-SB)**
 - ↳ Chapter 'Configuring the bus communication (ST-87x-SB/ST-88x-SB)' on page 87
 - Configure the rail bus communication between vehicle control system and iDM system or bus master system.

- (4) **Test control system**
 - ↳ Chapter 'Test control system' on page 88
 - Test sensors and peripheral devices
 - Test motor functions
 - Test communication

- (5) **Optimise settings**
 - ↳ Chapter 'Optimise settings' on page 93
 - Adapt vehicle parameters to ambient conditions.
 - Adapt configuration switches to ambient conditions.
 - Adapt vehicle tables to ambient conditions.

- (6) **Control system is ready for operation.**

8.4 Switch on control system



NOTICE!

Motor current configuration

Motor currents that are set too high may damage any "small" motors that are connected.


- Check motor current settings (parameters) prior to activation.



Automatic start-up

- After activation, the control system goes into automatic mode autonomously

→ Set start/stop switch to [I]



⇒ The control system starts.

Display during activation

After switching on, the display shows the "Conductix" logo during the start delay period.

The start delay is set in parameter [T0].



Fig. 16: Display during activation

**Missing parameters**

Since there are not yet any parameters in the control system, error messages are displayed after the start process.

The [Error] LED flashes or lights up permanently.

↪ Chapter 'Status LEDs' on page 100


8.5 Assign control system parameters

This chapter describes the basic procedure for assigning parameters to a vehicle control system.

Defined data records are edited by means of the MU-705 manual programming device or the MU-705 Utility software, and then transferred to the vehicle control system using the MU-705 manual programming device. Once the transfer is completed successfully, the vehicle control system has parameters assigned.

These data records consist of:

- Parameters and configuration switches
- Vehicle tables



Reference

Information on the MU-705 manual programming device can be found in the document:

- *BDA_0005_MU-705.pdf*

This document is part of the project documentation and is available for download at www.conductix.com.



Reference

Information on the MU-705 Utility software can be found in the document:

- *MU-705 Utility v2.x_PB0001.pdf*

This document is part of the project documentation and is available for download at www.conductix.com.



Rail bus projects

In rail bus projects (ST-87x-SB/ST-88x-SB), it is also possible to edit, save and transfer parameters, configuration switches and tables to the vehicle control system using the iDM-SyMa (iDM system) or DKZ-Para (bus master system).

Requirement: properly configured iDM system or bus master system

Information on the iDM-SyMa can be found in the document:

- *SWB_0005_iDM-SyMa.pdf*

Information on the DKZ-Para can be found in the document:

- *DKZPARAM Win v3.x TCPIP_PB0006.pdf*

These documents form part of the project documentation or can be downloaded from www.conductix.com.

8.5.1 Vehicle parameters and configuration switches

The data records for vehicle parameter assignment, in which values are defined for particular vehicle functions, consist of vehicle parameters and configuration switches.

The vehicle behaviour is specified using vehicle parameters and the configuration switches. Furthermore, different control system functions can be activated, deactivated and modified. The parameters are set according to the system requirements.



Monitoring

All monitors are always activated. Unnecessary monitors must be deactivated during commissioning, depending on the application.



Reference

Information on the vehicle parameters and configuration switches used can be found in the project-specific software description BV, included in the scope of delivery!

Parameter values

Positive values from 0 to a maximum 65535 can be set as parameter values. The value range is limited further for some parameters.



Parameter values

Parameter values are held by the MU-705 manual programming device at reasonable limits.

It is not possible to set a value beyond this defined range with the MU-705 manual programming device. If parameters have to be transferred to the control system in a way other than using the MU-705 manual programming device, you have to note the specified value range. If a parameter value is outside the specified limits, this may lead to a vehicle control system malfunction or to an error message.



NOTICE!

Pre-set parameter values in the MU-705 manual programming device

All parameters on the delivered MU-705 manual programming device are pre-set with valid values, although not necessarily ones that conform to the system requirements.

- Every parameter value must be checked!

Configuration switch

Configuration switches are a part of the vehicle parameters. They activate or deactivate individual control system functions.

Each configuration switch can only assume one of two states:

- on
- off

8.5.1.1 Creating and saving parameters and configuration switches

Parameters and configuration switches are edited and saved in the MU-705 manual programming device and in the MU-705 utility software.

The parameters are organised for processing according to the logical sequence of the parameter assignment steps.

If a MU-705 manual programming device is delivered for control purposes, all the parameters and configuration switches specific to the control system are pre-set with valid values, but not necessarily those that conform to the system requirements. The *[PAR]* parameter (release key) is one exception.

Editing and saving parameters and configuration switches with the MU-705 manual programming device:

1. ➤ Open menu item "Parameters" → "Modify data".
2. ➤ Edit parameters or configuration switches.

3. Press ESC to exit menu item.

⇒ Modifications to the parameters and configuration switches are stored in the MU-705 manual programming device.

**Creating individual parameters**

If only individual parameters of a pre-configured vehicle control system have to be adjusted as part of system optimisation, it is recommended to read and archive the parameters and settings for the configuration switches from the vehicle control system prior to modification. This ensures that the values in the MU-705 manual programming device match those in the vehicle control system.

**NOTICE!****Regular data backups**

Property damage may result from data losses.

- Regularly perform backups of your data onto a separate computer.
- For backups on a PC, it is recommended to use the MU-705 Utility program.

**Rail bus projects**

In rail bus projects, it is also possible to edit, save and transfer parameters, configuration switches and tables to the vehicle control system using the iDM-SyMa (iDM system) or DKZ-Para (bus master system).

Requirement: properly configured iDM system or bus master system

8.5.1.2 Transferring parameters and configuration switches

Parameters and settings of the configuration switch are transferred to the vehicle control system using the MU-705 manual programming device.

Transferring parameters and configuration switches with the MU-705 manual programming device:

- 1.** Open menu item "Parameters" → "Write data".
- 2.** Press the F1 key [Yes] to confirm the 'Send' request.

3. Establish infrared communication.

- ⇒ Parameters and settings of the configuration switch are transferred from the MU-705 manual programming device to the vehicle control system.

**Parameters and configuration switches**

The parameters and settings of the configuration switches are always transferred together!

**Rail bus projects**

In rail bus projects, it is also possible to edit, save and transfer parameters, configuration switches and tables to the vehicle control system using the iDM-SyMa (iDM system) or DKZ-Para (bus master system).

Requirement: properly configured iDM system or bus master system

8.5.2 Vehicle tables – PCM system (ST-87x/ST-88x)

Vehicle tables contain data used by certain control system functions. This data is assigned to the system in which the vehicle control system is used.

The vehicle tables are used to set values that affect the motion and positioning functions.

These tables are:

- Configuration tables
- Speed tables
- Distance tables



Reference

Information on the tables used!

- *Information on the tables used can be found in the project-specific software description BVxxxxx, included in the scope of delivery!*



NOTICE!

Table values as per checked system documentation

For fault-free operation of the vehicles, the table values must be checked using the system documentation.

Configuration table

In the PCM command system, different half-cycle patterns are transferred to the vehicle control system via the PCM hardware. The vehicle control system is able to recognise these commands and adjust its behaviour accordingly. The PCM configuration table defines how the vehicle control system behaves with a PCM command.

Speed table

Speed tables allow you to define various speeds, which are accessed by the vehicle control system. Access to the individual speeds in this table is gained via an index. This is defined depending on the type of application or can be set through the PCM configuration table. This allows various speeds to be specified, for example, for various sectors in a plant.




Distance table

In order to avoid vehicle collisions (distance control), it is possible to define various distances in the distance tables, which are then accessed by the vehicle control system. Access to the individual distances is gained via an index. This is defined depending on the type of application or can be set through the PCM configuration table. Thanks to the variable configuration of a distance sensor, it is possible to implement various distances.

8.5.2.1 Creating and saving vehicle tables

Vehicle tables are edited and saved in the MU-705 manual programming device and in the MU-705 utility software.

Editing and saving tables with the MU-705 manual programming device:

1.  Open menu item "Tables" → "...table" → "Modify tab."
2.  Edit table.
3.  Press ESC to exit menu item.
 - ⇒ Modifications to the table are stored in the MU-705 manual programming device



Editing individual table entries

If only individual table entries of a pre-configured vehicle control system have to be adjusted as part of system optimisation, it is recommended to read and archive the tables from the vehicle control system prior to modification. This ensures that the values in the MU-705 manual programming device match those in the vehicle control system.



NOTICE!

Regular data backups

Property damage may result from data losses.

- Regularly perform backups of your data onto a separate computer.
- For backups on a PC, it is recommended to use the MU-705 Utility program.

8.5.2.2 Transferring vehicle tables

Vehicle tables are transferred to the vehicle control system using the MU-705 manual programming device.



Vehicle tables

Vehicle tables can be transferred individually or all together!

Transferring an individual table with the MU-705 manual programming device:

1. ▶ Open menu item "Tables" → "...table" → "Write tab."
2. ▶ Press the F1 key [Yes] to confirm the 'Send' request.
3. ▶ Establish infrared communication.
 - ⇒ The selected table is transferred from the MU-705 manual programming device to the vehicle control system.

Transferring all tables with the MU-705 manual programming device:

1. ▶ Open menu item "Tables" → "All tables" → "Write".
2. ▶ Press the F1 key [Yes] to confirm the 'Send' request.
3. ▶ Establish infrared communication.
 - ⇒ All tables are transferred from the MU-705 manual programming device to the vehicle control system.

8.5.3 Vehicle tables – rail bus SB (ST-87x-SB/ST-88x-SB)

Vehicle tables contain data, which is accessed by certain control system functions. This data is assigned to the system in which the vehicle control system is used.

The vehicle tables are used to set values that affect the motion and positioning functions.

These tables are:

- Segment tables
- Speed tables
- Distance tables
- Stop-offset tables



Reference

Information on the tables used!

- *Information on the tables used can be found in the project-specific software description BVxxxxx, included in the scope of delivery!*



NOTICE!

Table values as per checked system documentation

For fault-free operation of the vehicles, the table values must be checked using the system documentation.

Segment table

The segment table is the image of a system/ system section. In order to be able to define control system behaviour in different subsections of the system, the system is divided into segments based on the position value. The control system behaviour – e.g. speed, distance, positioning, etc. – can be configured in this table for each segment.

Speed table

Speed tables allow you to define various speeds, which are accessed by the vehicle control system. Access to the individual speeds in this table is gained via an index. This is defined depending on the type of application or can be set through the segment table. The segment table defines which speed index applies for which system segment. Based on the system position, the vehicle control system identifies the current segment and proceeds at the specified speed. This allows the specification of various speeds for cornering, straight travel, etc.




Distance table Distance tables allow you to define various distances, which are accessed by the vehicle control system. Access to the individual distances is gained via an index. This is defined depending on the type of application or can be set through the segment table. The segment table defines which distance index applies for which system segment. Based on the system position, the vehicle control system identifies the current segment and maintains the set distance to the preceding vehicle. This allows the specification of distances, such as the ones related to buffer zones, bends, etc.

Stop-offset table A fixed stop point is defined in the segment table during positioning. With the help of the stop-offset table, the vehicle can stop earlier by a particular value defined in the table. Access to the individual stop-offset is gained via an index. The stop-offset index to be used is specified directly by the system controls. This, for instance, allows a vehicle to be positioned according to its load.

8.5.3.1 Creating and saving vehicle tables

Vehicle tables are edited and saved in the MU-705 manual programming device and in the MU-705 utility software.

Editing and saving tables with the MU-705 manual programming device:

1.  Open menu item "Tables" → "...table" → "Modify tab."
2.  Edit table.
3.  Press ESC to exit menu item.
 - ⇒ Modifications to the table are stored in the MU-705 manual programming device



Editing individual table entries

If only individual table entries of a pre-configured vehicle control system have to be adjusted as part of system optimisation, it is recommended to read and archive the tables from the vehicle control system prior to modification. This ensures that the values in the MU-705 manual programming device match those in the vehicle control system.



NOTICE!

Regular data backups

Property damage may result from data losses.

- Regularly perform backups of your data onto a separate computer.
- For backups on a PC, it is recommended to use the MU-705 Utility program.



Rail bus projects

In rail bus projects, it is also possible to edit, save and transfer parameters, configuration switches and tables to the vehicle control system using the iDM-SyMa (iDM system) or DKZ-Para (bus master system).

Requirement: properly configured iDM system or bus master system

8.5.3.2 Transferring vehicle tables

Vehicle tables are transferred to the vehicle control system using the MU-705 manual programming device.



Vehicle tables

Vehicle tables can be transferred individually or all together!

Transferring an individual table with the MU-705 manual programming device:

1. ➤ Open menu item "Tables" → "...table" → "Write tab."
2. ➤ Press the F1 key [Yes] to confirm the 'Send' request.
3. ➤ Establish infrared communication.
 - ⇒ The selected table is transferred from the MU-705 manual programming device to the vehicle control system.

Transferring all tables with the MU-705 manual programming device:

1. ➤ Open menu item "Tables" → "All tables" → "Write".
2. ➤ Press the F1 key [Yes] to confirm the 'Send' request.

3. Establish infrared communication.

- ⇒ All tables are transferred from the MU-705 manual programming device to the vehicle control system.

**Rail bus projects**

In rail bus projects, it is also possible to edit, save and transfer parameters, configuration switches and tables to the vehicle control system using the iDM-SyMa (iDM system) or DKZ-Para (bus master system).

Requirement: properly configured iDM system or bus master system

8.6 Configuring the bus communication (ST-87x-SB/ST-88x-SB)

In order for the vehicle control system to be able to communicate with the iDM system or the bus master system via the rail bus and thus with the PLC, the bus communication must be configured properly.

These settings depend on the project.



Rail bus projects (ST-87x-SB/ST-88x-SB)

Required for the configuration of the bus communication in the iDM system:

- *Project-specific software description BVxxxxx, included in the scope of delivery*




Required for the configuration of the bus communication in the bus master system:

- *Project-specific software description BVxxxxx, included in the scope of delivery*
- *Project-specific interface description BVxxxxx, included in the scope of delivery*

These documents contain all the information on the configuration settings of the bus communication.

8.7 Test control system

The following parameters can be tested after parameter assignment:

-  Chapter 'Test – motor functions' on page 88
-  Chapter 'Test – Sensors and peripherals' on page 90
-  Chapter 'Test – Communication' on page 91



To be observed at all times!

This chapter deals with the key assignment of the hand-held remote control as well as the names used for display modes, error codes, parameters, etc. These are standard assignments/names.

The key assignment of the hand held remote control as well as the names for display modes, error codes, parameters, etc. may vary according to the project.

Required for the control system test:

- *Project-specific software description BV, included in the scope of delivery*

8.7.1 Test – motor functions



⚠ WARNING!

Unchecked parameter values

Unchecked parameter values can lead to uncontrolled drive movements.

- Decouple gear system before first test.



⚠ WARNING!

Non-standard key assignment on the hand-held remote control

The drive can perform undesired movements if a different key is assigned on the hand-held remote control.


- Observe the remote control commands in the project-specific software description BV, included in the scope of delivery!

Motor function test

When testing the motor function, the mechanical and electrical function and the correct parameter assignment of the drivetrain are checked.

To give brief commands to the control system, using the remote control is recommended. For the control system to respond to the commands of the remote control, the control system must be in manual mode.

**Activating manual mode with the remote control**

Manual mode is activated by pressing the star button  of the remote control. Manual operating mode is displayed in the control system by the blue LED flashing once or twice.



Motor rotation test

To test motor rotation, a motion command is transmitted to the control system using the remote control.

**NOTICE!****High motor speed**

Damage to the motor and gear system

- For the initial start-up, a slow manual speed (e.g. 5,000 mm/min) should be selected. This is set under V14 of the speed table (asynchronous).

1. Press right direction button 
 - ⇒ Opens mechanical brake (if available)
 - Motor rotates
2. Press left direction button 
 - ⇒ Opens mechanical brake (if available)
 - Motor rotates





During the test make sure that:

- *The motor is rotating in the specified direction.*
- *The rated current is not exceeded.*
- *The motor overrun is quiet.*

Brake test

If the motor used has a mechanical brake, this can be opened regardless of the rotation of the motor shaft. To test the brake, an "Open brake" command is transmitted to the control system using the remote control.

- ➔ Hold down the star  and arrow-up  buttons simultaneously
- ⇒ When the brake is opened an audible click will be heard.

Motor temperature sensor test

If the connected motor(s) is/are equipped with a temperature sensor, you can test whether it is working or not. You can check whether the control system is reading a valid temperature/resistance value in **display mode 6** (motor temperature).

↪ Chapter 'Display modes' on page 104



Temperature monitoring can be deactivated through the set configuration switch [SW16].

If the control system cannot read any values, excess temperature error [F114] is displayed. Possible causes:

- Wiring fault
- No temperature sensor installed or connected

8.7.2 Test – Sensors and peripherals**Binary input test**

Switching states of the connected components can be displayed and checked using the **display mode 040** (I/O card inputs). Each activated input of the I/O card sets a defined bit in the display value.

By setting or deleting an input bit, the value in the display can be checked.

↪ Chapter 'Display modes' on page 104

Binary output test

The **Display mode 041 (I/O card outputs)** can be used to check the switching states of the I/O card outputs. Outputs are set in a test-like manner using the parameter "Output test – Configuration" [CTsO].

For outputs to be activated in this way, the control system must be in unrestrained manual mode (configuration switch [SW12]).

For the output test, the relevant bit must be set in the parameter "Output test – Configuration" [CTsO] and the switch status checked in **display mode 41** (I/O card outputs) and on the corresponding output component.

↪ Chapter 'Display modes' on page 104

Bus components test

Position encoders, distance sensors and vehicle address boxes can be used as bus components. The bus components must support the LJU bus protocol.



The relevant component must be selected (parameter "Input X16– Configuration" [CI16]) and connected to the control system [X16].

If the bus components are properly connected and configured, values are displayed in the relevant display modes.

Display mode 036 (Encoder position – unfiltered [mm]):
Position encoder = Position value

Display mode 038 (Current distance encoder value [mm]):
Distance sensor = Distance value

Display mode 080 (Vehicle number):
Vehicle address box = Vehicle number

If the connection cable between the control system and bus component is removed, an offline error must appear.

↪ Chapter 'Display modes' on page 104

8.7.3 Test – Communication

PCM commands / messages

Requirement for the automatic operation of the vehicle is the detection and processing of commands. You can check whether or not these arrive correctly at the control system via **display mode 050** (PCM command). This displays the incoming PCM command as a decimal value.

If **Z-stop** is used, the signal detection on the control system must be tested. A Z-stop signal is placed on the relevant rail by a vehicle in the successor segment. Only the signal input can be checked in **display mode 053** (Z stop). Since the Z-stop signal is a full wave, 202 must be shown in the display.

The transmission of messages to the signal rail is important as feedback for system control. Depending on the configuration, the relevant control system statuses (error status, manual mode, positioned, etc.) must be established for this to occur. The messages can be checked on the system PLC or using the LED statuses on the PCM input module.

Rail bus communication

In the case of vehicle control systems with rail bus communication, commands and messages are exchanged through the rail bus. To test this, the control system must be registered on the TCU or bus master.



In addition to correct wiring and parameter configuration, a requirement for registration is the existence of a valid position value ($\neq 0$) as well as a valid vehicle number ($\neq 0$).

Communication is successful if the control system can be registered.

As an additional control option, it is possible to compare the command and status words of the TCU or bus master and the control system using **display mode 120** (PLC command A + B) and **display mode 121** (PLC status A + B).

8.8 Optimise settings

Motor settings

Motor parameter optimisation follows two opposing objectives.

- The motor current should be as low as possible so that the motor does not overheat and consumes little power.
- The motor should have sufficient force to move the vehicle and its load safely and reliably at all times.

When the motor has correct parameter assignment in the parameters "Motor – Rated current" [*In1*], "Motor – Stator resistance" [*Rs1*] and "cut-off frequency" [*Fn1x*], the motor is essentially well configured. The current consumption can be varied with the "I × R compensation factor" [*IR1x*] for low to medium frequencies.



NOTICE!

Higher rated current

Excessive rated current may lead to motor overload!

- The rated current should only be exceeded for large loads; e.g. when braking and accelerating, as well as ascending and descending movements.

Brake and acceleration ramps

When setting the parameters for braking and accelerating ramps in the respective movement modes (normal movement, ascent, descent, synchronous movement, special movement), the best of two opposing target settings must be found.

- Steep ramps
 - Quick accelerating and braking.
 - High wear due to high mechanical loads.
- Gentle ramps
 - Slow accelerating and braking.
 - Low wear due to light mechanical loads.

Configuration with jerk limiting (parameter "Jerk limit – Configuration" [*Cj_*]) enables gentle acceleration and braking.

Frequency for opening and closing the brake

The frequency should be selected low wherever possible, since starting against a closed brake will result in mechanical load and high motor current.

Settings are made in the parameters of the modes of movement (normal movement, ascent, descent, synchronous movement, special movement).

***Increase frequency for opening and closing the brake***

This frequency can be raised in ascending and descending movements to prevent the vehicle from rolling forwards or backwards unintentionally.

Time delays

If an old control system has to be replaced with a ST-87x / ST-88x, one notices that it often responds more quickly to input signals (PCM and component inputs). To compensate for this time shift, delay times can be set for commands with the parameters "PCM command – Command change delay" $[TPc0]$ and $[TPc]$ and for components with the parameter "Detection delay time" $[TDxx]$.

9 Operation

Objective	This section explains the work steps required by the operator.
In daily operation	<p>In daily operation the system is used in automated fashion, so that:</p> <ul style="list-style-type: none"> ■ The safety of personnel is ensured. ■ Workflows and functions are monitored using control system technology. ■ Trained users are supported in ongoing processes at regular intervals.
Responsible party	<p>The operator, or supervisory personnel appointed by him, is responsible for a safe and seamless workflow. As the contact person, he responds to all the personnel's queries regarding safe-to-use equipment; e.g.:</p> <ul style="list-style-type: none"> ■ Fire protection ■ Electrical equipment
Required personnel	<p>Due to their training and experience, only qualified and appropriately instructed personnel are able to correctly assess the respective initial situation, identify risks and avoid hazards.</p> <p>Personnel required for everyday operation:</p> <ul style="list-style-type: none"> ■ Qualified and appropriately instructed operating personnel ■ Qualified and appropriately instructed maintenance personnel
Required personal protective equipment	<p>The person responsible must ensure that the personnel under his responsibility are wearing the required personal protective equipment. The required personal protective equipment satisfies the requirements for the work to be carried out and all the requirements demanded by the scope of work.</p> <p>Personal protective equipment that fulfils its intended purpose:</p> <ul style="list-style-type: none"> ■ protects its wearer from injury; ■ reduces the seriousness and severity of potential injuries. <p>Wear:</p> <ul style="list-style-type: none"> ■ Work protection clothing ■ Safety shoes ■ Protective gloves ■ Protective goggles
Safety in the work area	<ul style="list-style-type: none"> ■ Only work when protection and monitoring equipment are active. ■ Pay attention to the safety signs at the work station and its immediate vicinity. ■ Only load load-bearing machinery within the permitted limits. ■ Secure goods to be transported against loss.



Work safety

Pay attention to company and task-specific work safety regulations, as well as the country-specific legal and safety regulations applicable at the location of use.



Wear additional protective equipment

As an employee, you wear protective equipment supplied by the area supervisor. If work tasks have been delegated only temporarily, then you also wear any protective equipment that has become additionally required.

Special hazards



⚠ WARNING!

Automatic start-up

Danger posed by unintended activation of the control system and start-up of motors and drive units.

Risk of crushing limbs, catching and dragging of loose items of clothing due to moving machine parts

- No persons in the danger zone of moving system parts
- Deactivate automatic start-up
- Only activate control system under supervision
- If necessary, disengage the drive.
- If necessary, disconnect the vehicle from voltage.
- Keep clear of moving system parts.
- Do not reach into the running machine.
- Wear tight-fitting work clothes.
- Pay attention to optical and acoustic warning equipment.



⚠ WARNING!

Hazardous voltages on ports and cables

Open electrical components

- Do not pull plugs carrying voltage.
- Do not contact open cables.



⚠ WARNING!

Start/stop switch

The start/stop switch does not disconnect the controller from the power supply. Dangerous voltage is present.

- Installation of a main switch by the system operator or system manufacturer.
- All poles of the power supply must be able to be switched off and protected against being switched on again.
- The control system must be disconnected from the power supply when performing work on it.



⚠ WARNING!

Risk of fire due to hot surfaces

Highly flammable materials may catch fire if they come in direct or indirect contact with the hot surfaces of the device.

- Ensure that the air around the device is constantly circulated.
- Do not place any flammable materials on top of the device.
- Keep flammable materials away from the housing surface and the heat sink.



⚠ CAUTION!

Hot surfaces

Risk of burns posed by hot surfaces of the control system and connected components.

- Install protective equipment and check it regularly.
- Prior to working on the control system, allow the connected components to cool down.

9.1 Operating modes

Operating modes

The control system can be operated in the following ways:

- Automatic mode
- Manual mode
- Unrestrained manual mode

Automatic mode

In automatic mode, the control system responds to PCM or rail bus commands of the higher-level system controller, or the control system works through an internally defined motion program. In the event of faults, the control system stops.

Manual mode

The control system can be operated via the remote control in manual mode. Errors are only evaluated to a limited degree in manual mode. When switching to manual mode or back to automatic mode, any present errors are reset. If the cause of the problem continues to exist, however, then the relevant message appears on the display.


Unrestrained manual mode

In unrestrained manual mode, it is possible to operate the control system despite faults being present. The control system responds exclusively to converter, data bus and communication errors. Software restrictions set through parameters are taken out of action in this operating mode. Hardware-induced restrictions remain in place.

9.2 Switching the control system on and off**9.2.1 Switch on control system****Automatic start-up**

- After activation, the control system goes into automatic mode autonomously

➔ Set start/stop switch to [I]



⇒ The control system starts.

Display during activation

After switching on, the display shows the "Conductix" logo during the start delay period.


The start delay is set in parameter $[T0]$.



Fig. 17: Display during activation

9.2.2 Switches the control system off

➔ Set start/stop switch to $[0]$




Display during shutdown

If the control system is switched off, the display shows the inverted "Conductix" logo.



Fig. 18: Display during shutdown

9.3 Displays



- 1 Status LEDs
- 2 Display

9.3.1 Status LEDs

- LED – Error
- LED – Status 1
- LED – Status 2



Status LEDs for PCM and rail bus communication

The meaning of LEDs differs depending on communication version of the vehicle control system.

- Pulse Code Modulation (PCM)
- Rail bus communication (SB)

LED – Error

Message	Meaning	SB	PCM
Off 	Control system is fault-free	✓	✓
On - Lights up permanently 	Control system is in automatic mode and no vehicle was found	✓	
Flashing - LED flashes (on/off each time approx. 1 sec) 	Control system has errors	✓	✓
Single flash - LED flashes once 	Stop activated	✓	✓

Tab. 16: Display – LED – Error

LED – Status 1

Message	Meaning	SB	PCM
Off ○	No meaning		
On - Lights up permanently ●	PCM command present and axis is driven		✓
Flashing - LED flashes (on/off each time approx. 1 sec) ⚡○ ○ ⚡○ ○	PCM command present		✓
Single flash - LED flashes once ⚡○ ○ ⚡○ ○	Control system is in manual mode	✓	✓
Double flash - LED flashes twice ⚡⚡○ ○ ⚡⚡○ ○	Control system is in unrestrained manual mode	✓	✓

Tab. 17: Display – LED – Status 1

LED – Status 2

Message	Meaning	SB	PCM
Off ○	No meaning		
On - Lights up permanently ●	Vehicle position is positioned and standing	✓	✓
Flashing - LED flashes (on/off each time approx. 1 sec) ⚡○ ○ ⚡○ ○	Vehicle stops – Z-stop		✓
	Vehicle stops – Distance check	✓	
Single flash - LED flashes once ⚡○ ○ ⚡○ ○	Vehicle stops – Approach sensor	✓	✓
Double flash - LED flashes twice ⚡⚡○ ○ ⚡⚡○ ○	Vehicle stops – Distance sensor	✓	✓

Tab. 18: Display – LED – Status 2

9.3.2 Display

Display during activation

After switching on, the display shows the "Conductix" logo during the start delay period.

The start delay is set in parameter $[T0]$.



Fig. 19: Display during activation

Display during shutdown

If the control system is switched off, the display shows the inverted "Conductix" logo.



Fig. 20: Display during shutdown

Display layout

The display can be toggled:

- Display layout – **Standard**
- Display layout – **Extended**

The display layout can be switched between standard and extended by setting the $[SW1]$ configuration switch in the manual programming device.

Display presentation – Standard

Four lines each with the number of the display mode and its value are shown on the display by default. Which values are displayed can be configured.




Fig. 21: Display – Standard presentation

- 1 Display mode **002** – Target speed: 50 mm/min
- 2 Display mode **010** – Stopping distance from actual speed: 132 mm
- 3 Display mode **210** – Debug area (relevant for the service team): hexadecimal display

Display presentation – Extended

An individual display value can be presented in large digits for better legibility from long distances. In a second line, the unit and the number of the displayed value are shown in a smaller size type.




Fig. 22: Display – Extended layout

- 1 Display mode
- 2 Value
- 3 Unit

Infra-red communication

In the case of infra-red communication, the presentation on the display is inverted.



Fig. 23: Display during infra-red communication

Fault indicator

If the vehicle is in error mode, the error number and a red LED flash. Error number and error message are shown in alternation.

If more than one error is active, the various numbers and messages are displayed one after the other.

The error number is composed of a large "F" and a three-digit hexadecimal number.




Fig. 24: Display – Error message



Fault indicator can be deactivated through configuration switch [SW13].

9.3.3 Display modes

The display mode refers to the numbering of the respective status information shown in the display. The display can be configured using the numbering.

(e.g.: Display mode 002 shows the set speed)

values are shown in **decimal** or **hexadecimal** format.

- Decimal values can be read directly.
- Hexadecimal values are indicated by a "h" behind the value and must be converted for calculation.

If multiple lines of the legend apply, the bits are added. ↪ *Chapter 'Calculating and evaluating hexadecimal values' on page 105*



Verweis

The display modes used may vary according to the control system!

- *Observe the project-specific software description BVxxxx, included in the scope of delivery!*

This document contains all the information on the display modes.

9.3.3.1 Creating/modifying display modes

Display modes are selected in the MU-705 manual programming device.



Reference

For information about the manual programming device, please refer to the corresponding operating manual:

- BDA_0005_MU-705.pdf

The operating manual is part of the project documentation or can be downloaded from www.conductix.com.

A maximum of four display modes can be displayed simultaneously.

The first display mode entered is displayed in the fourth line of the display. The last display mode entered is displayed in the first line of the display.

If more than four numbers are entered, the number first entered is deleted again.

1. ➤ Switch on the manual programming device.
2. ➤ Open the following menu items in the manual programming device: 'Target/number → Display'
3. ➤ Enter the number of the display mode which is to be displayed in the last line.
4. ➤ Transfer change to the vehicle control system.



Distance between the manual programming device and the control system

Data is transferred via infra-red. For successful data transmission, the distance to the display of the control system and the IR receiver may be max. 1 m at an angle of 16°.

5. ➤ Repeat the process for all display modes that are to be displayed.

9.3.3.2 Calculating and evaluating hexadecimal values

Some values are displayed in the form of a four-digit hexadecimal number on the display. To evaluate what the displayed number means, the number must be converted into binary format.

Hexadecimal	0	1	2	3	4	5	6	7
Binary	0000	0001	0010	0011	0100	0101	0110	0111
Hexadecimal	8	9	A	B	C	D	E	F
Binary	1000	1001	1010	1011	1100	1101	1110	1111

Example**Hexadecimal number: 8E01**

	8	E	0	1
	1 0 0 0	1 1 1 0	0 0 0 0	0 0 0 1
Bit	16	12 11 10		1

Meaning in display mode 011 "Inverter status"

Bit 1	Enabling set
Bit 10	Error in error group 1
Bit 11	Error in error group 2
Bit 12	Set speed reached
Bit 16	Stopped due to distance check

**Meaning of set bits**

The meaning of set or non-set bits can be found in the legend of the respective display mode.

9.4 Vehicle remote control

In automatic mode, the control system receives the relevant commands for moving the vehicle from the higher-level system controller or runs an internal driving program.

In manual or unrestrained manual mode, the vehicle can be moved manually using optional hand-held remote controls (FB) or a manual programming device (MU).



Reference

Information on the hand-held remote controls can be found in the corresponding operating manual:

- *BDA_0002_FB-606.pdf*
- *BDA_0003_FB-706.pdf*
- *BDA_0018_FB-8.pdf*

The operating manuals are part of the project documentation or can be downloaded from www.conductix.com.



Reference

For information about the manual programming device, please refer to the corresponding operating manual:

- *BDA_0005_MU-705.pdf*

The operating manual is part of the project documentation or can be downloaded from www.conductix.com.

9.4.1 Changing operating mode



⚠ WARNING!


Automatic start-up

Risk of fatality due to moving machine parts!


If the control system is in automatic mode or is going to be switched to automatic mode, an automatic start-up of the system is to be expected at any time.

- No persons in the danger zone of moving system parts!
- Only activate the control system under supervision!

Activating manual mode

- ➔ Press the button  on the remote control in automatic mode.
 - ⇒ The vehicle control system is in manual mode. The blue LED is flashing.

Activating automatic mode

- ➔ Press the button  on remote control in manual mode.
 - ⇒ The vehicle control system is in automatic mode.

Activating unrestrained manual mode

- ➔ Activate *[SW12]* configuration switch in the manual programming device and transfer the new configuration to the vehicle control system.

9.4.2 Moving the vehicle manually



⚠ WARNING!

Danger of crushing

When moving vehicles in **manual mode** or **unrestrained manual mode**, safety equipment or safety functions may be deactivated.

Death or serious injuries could result.

- The moving of vehicles in **manual mode** or **unrestrained manual mode** must only be performed by instructed personnel.
- When moving vehicles in **manual mode** or **unrestrained manual mode**, there should be no people in the action area of the vehicle.
- Operate the vehicle remotely only when it is in the line of sight.



⚠ WARNING!

Non-standard key assignment on the hand-held remote control

The drive can perform undesired movements if a different key is assigned on the hand-held remote control.

- Observe the remote control commands in the project-specific software description BV, included in the scope of delivery!

Movement with remote control

In manual mode and unrestrained manual mode, the vehicle can be controlled using the remote control by means of the following buttons.

Key	Function
	Switchover to manual mode
	Switchover to automatic mode
+	Release brake
	Slow forwards movement
+	Fast forwards movement
	Slow backwards movement
+	Fast backwards movement



Vehicle/control system stop

The movement is performed for as long as the button – or buttons, in the case of fast movements – are released. In this process the movement is not stopped abruptly. Instead it is cushioned by the control system.



Distance between the the remote control and the control system

The commands are transmitted via infra-red. The range of the remote control is at least 6 m with a transmission/reception angle of $\pm 24^\circ$ to the display of the control system or the IR receiver.

Moving with the manual programming device

In manual mode and unrestrained manual mode, the vehicle can be controlled using the remote control by means of the following buttons.

Key	Function
5	Switchover to manual mode
	Switch between slow manual mode and fast manual mode
7	Switchover to automatic mode
F3 or 6	Forwards movement (slow or fast)
F1 or 4	Backwards movement (slow or fast)
* + ↑	Release brake



Distance between the manual programming device and the control system

Data is transferred via infra-red. For successful data transmission, the distance to the display of the control system and the IR receiver may be max. 1 m at an angle of 16° .

10 Faults



Note

Any detected malfunction automatically leads to an immediate stop of the vehicle!

10.1 Displaying faults and errors

Fault indicator

If the vehicle is in error mode, the error number and a red LED flash. Error number and error message are shown in alternation.

If more than one error is active, the various numbers and messages are displayed one after the other.

The error number is composed of a large "F" and a three-digit hexadecimal number.




Fig. 25: Display – Error message



Fault indicator can be deactivated through configuration switch [SW13].

10.2 Error messages



Error message – PCM communication

Errors are transmitted via the signal rail to the system controller as collective faults.



Error message – Bus communication

Errors that occur on the control system are forwarded on to the higher-level system controller and can also be displayed there, depending on the system controller.



Reference

Information on the error messages used!

- Observe the project-specific software description *BVxxxxx*, included in the scope of delivery!

This document contains all the information on the error messages.

10.3 Error codes

Error codes are displayed with an 'F' and 3 digits.

	1st digit	2nd digit	3rd digit
Converter fault			
F	0	0 ^E ; 1 ^F , 2 ^F , 3 ^F , 4 ^F , 5 ^F , 6 ^F , 7 ^F , 8 ^F , 9 ^F	0...9 / A...F
Axis-related fault			
F	1 ^{A,D} / 2 ^{B,D} / 3 ^D / 4 ^D / 5 ^D / 6 ^D / 7 ^D	1...7	0...9 / A...F
Safety circuit fault			
F	8	0...9 / A...F	0...9 / A...F
Application error			
F	A	0...9 / A...F	0...9 / A...F
I/O system error			
F	B	0...9	0...9 / A...F
Communication error			
F	C	0...9 / A...F	0...9 / A...F

Data error			
F	D	0, 1	0...9 / A...F
External device fault ^c			
F	E	0...9 / A...F	0...9 / A...F

^A Axis 1 is always the motion axis (except vehicles without motion drive)

^B Axis 2 is always the stroke axis (only relevant for control systems from ST-89x)

^C Error code (only for control systems ST-88x, ST-89x as well as special control systems)

^D Motion axis number

^E Infeed/supply

^F Frequency converter number

Tab. 19: Error codes

10.4 Fault types

- **Faults to be acknowledged manually**
- **Self-acknowledging faults**

Faults to be acknowledged

Faults whose cause or effect could lead to personal injury, damage to the system or plant stoppages must be acknowledged.

All faults to be acknowledged manually are saved in the error log.

A **Resetting** of the error message can only be **performed** manually:

- **Manual reset**
- **Power on reset**

Self-acknowledging faults

Faults whose cause or effect do not lead to personal injury or damage to the system acknowledge themselves provided the cause of the fault is no longer present.

Self-acknowledging faults are saved in the error log.

The error message is reset automatically – **Self-reset**.



⚠ WARNING!

Automatic start-up

Danger posed by unintended activation of the control system and start-up of motors and drive units.

Risk of crushing limbs, catching and dragging of loose items of clothing due to moving machine parts

- No persons in the danger zone of moving system parts
- Deactivate automatic start-up
- Only activate control system under supervision
- If necessary, disengage the drive.
- If necessary, disconnect the vehicle from voltage.
- Keep clear of moving system parts.
- Do not reach into the running machine.
- Wear tight-fitting work clothes.
- Pay attention to optical and acoustic warning equipment.



NOTICE!

Monitoring the error log

Damage to the control system

Causes of self-acknowledging faults may re-appear.

- To prevent permanent damage, the error logs must be checked for abnormalities.

10.5 Fault reset

After eliminating the cause of the fault, a present fault can be reset.



Resetting faults:

- Manual Reset (MR)
- Power on Reset (POR)
- Self-Reset (SR)



Manual Reset (MR)

- Change operating mode
- Confirm operating mode
- Press start/stop switch

Change operating mode

1. ➤ Switching from automatic to manual mode
Press remote control button 
⇒ Fault acknowledged
2. ➤ Switching back from manual to automatic mode
Press remote control button 

Confirm operating mode

- Pressing the buttons for the current operating mode
Press remote control button  or 
⇒ Fault acknowledged

Press start/stop switch

- Pressing the start/stop switch
Press the start/stop switch on the control system
⇒ Fault is acknowledged after releasing the switch

Power on Reset (POR)

1. ➤ Switch off busbar or disconnect the control system from the busbar
⇒ Fault acknowledged
2. ➤ Switch on busbar / re-connect the control system to the busbar



*The option **Power on Reset** Only use if the fault was not reset by pressing the start/stop switch.*

Self-Reset (SR)

Self-acknowledging fault ↪ *'Self-acknowledging faults' on page 113*

Faults that reset themselves once the cause of the fault has been eliminated.

11 Service and maintenance

11.1 Maintenance and cleaning

Operation and maintenance

The operation and maintenance of the control system must only be performed by trained and qualified personnel. Staff undergoing instruction and training are allowed to perform activities on and with the control system under the constant supervision of a trained and qualified individual.



⚠ WARNING!

Danger to life from electrical current!

Contact with live parts poses an immediate danger to life.

- Disconnect the system from the power supply and secure it against being switched on again before servicing and cleaning the control system.



Opening the control system for testing purposes is not intended.

11.1.1 Maintenance



NOTICE!

Mechanical loads may lead to device failure.

- Check the device for damage at regular intervals.
- Opening the device for testing purposes is not intended.

Service the device as follows:

- **Brackets**
 - Check for loose connections.
- **Connections**
 - Check for loose connections.
 - Check cable insulation.
 - Cover any ports not being used.
- **Indicators**
 - Remove soiling.
- **Recommended maintenance interval**
 - 6 months

11.1.2 Cleaning



NOTICE!

Damage to the device due to improper cleaning

- Do not use any cleaning agents, such as methylated spirits, or other cleaners!
- Do not clean with sharp objects!

Clean the device as follows:

- **Device**
 - Clean with dry cloths only.
- **Recommended cleaning intervals**
 - 6 months

11.2 Removing / replacing the control system



⚠ WARNING!

Changing the control system

Danger posed by faulty installation.

Faults during installation may lead to potentially fatal situations or considerable material damage.

- Have installation performed exclusively by employees of the manufacturer or by trained personnel authorised by it.
- Works on electric components may only be carried out by qualified electricians or persons instructed and supervised by a qualified electrician in accordance with the electro-technical regulations.
- Only disconnect plug connections to external componentry when in a de-energised state.
- Before carrying out work on the control system, make sure it is de-energised and secured against accidental reactivation.
- Prior to commissioning, ensure that all safety equipment is installed and functioning properly.
- Prior to commissioning, ensure that parameter assignment on the device has been performed correctly in accordance with the electrical and mechanical conditions of the system.



⚠ WARNING!

Start/stop switch

The start/stop switch does not disconnect the controller from the power supply. Dangerous voltage is present.

- The control system must be disconnected from the power supply when performing work on it.

11.2.1 Control system removal



Reading parameters and tables

If possible, read and save the current parameters and tables from the control system using the MU-705 manual programming device.

How to remove the control system:

1. ➤ Switch off the control system with the start/stop switch.
2. ➤ Switch off the power supply and protect against accidental reactivation.



⚠ WARNING!

Electric shock due to capacitors not having fully discharged

Some components of the vehicle controllers, especially the intermediate circuit of the frequency inverters, may still retain voltage after switching off. Work on these components may only be carried out after the intermediate circuit has discharged!

Risk of fatality posed by electric shock!

Disconnect the power supply safely:

- Disconnect system from power
- Disconnect collector from busbar

Waiting time after voltage isolation: At least 10 minutes

3. ➤ Disconnect external connections.
4. ➤ If available: Remove the DataCom stick.
5. ➤ Disconnect mechanical connections.

11.2.2 Control system installation

How to install the control system:

1. ► Check the new control system for transport damage.
2. ► Install the control system mechanically.
3. ► Connect voltage-free external connections with the control system.
4. ► If available, connect the DataCom stick.
5. ► Put the control system into service. ↪ *Chapter 'Commissioning' on page 67*



Reading parameters and tables

Transfer saved parameters and tables of the 'old' control system to the control system using the MU-705 manual programming device.

(Configure vehicle number and type, if necessary.)

11.3 Repairing the control system

If a repair of the control system becomes necessary, please refer to your next service partner or go directly to Conductix-Wampfler Automation GmbH.

↪ *Chapter 'Customer service and addresses' on page 147*



Repairs

The repair of a defective control system must only be performed by the staff of Conductix-Wampfler or specialists trained by Conductix-Wampfler.

In the event of repairs by unauthorised persons, all warranty claims against Conductix-Wampfler Automation GmbH are invalidated.


12 Disposal

12.1 Information on disposal and environmental regulations

If no return or disposal agreements exist, the individual components are to be properly dismantled and then separated and disposed of pursuant to current regulations or taken for recycling.

The device comprises electric and electronic components. Separate and dispose of them according to applicable provisions.

Follow the hazardous materials directive, in particular the regulations on handling hazardous materials.

 Materials designated for recycling are to be disposed of as per the respective recycling procedure.

13 Technical specifications

13.1 Device

Dimensions

Type	Dimensions: W × H × D (mm)	
ST-870 / 880	200 × 200 × 90	
ST-871 / 881	200 × 200 × 90	
ST-872 / 882	200 × 200 × 119	
ST-873 / 883	200 × 200 × 131	Including mounting bracket

Tab. 20: ST-87x / 88x - Dimensions

Material




Fig. 26

- 1 Front and side plates
- 2 Profile corner
- 3 Mounting plate
- 4 Edge profile
- 5 Front film

Type	Material
Fig. 26/1	Aluminium
Fig. 26/2	Plastic ABS, green
Fig. 26/3	Aluminium
Fig. 26/4	Aluminium
Fig. 26/5	Polyethylene

Tab. 21: ST-87x / 88x material

Weight

Type	Weight (g)	
ST-870 / 880	approx. 3200	
ST-871 / 881	approx. 3200	
ST-872 / 882	approx. 4200	
ST-873 / 883	approx. 5100	Including mounting bracket

Tab. 22: ST-87x / 88x weight

Environmental conditions

Environmental conditions		
Climatic ambient conditions As per DIN IEC 60721-3-3	Category: 3K3 (Fixed-location usage*; weatherproof)	
Mechanical environmental conditions As per DIN IEC 60721-3-3	Category: 3M4 (Fixed-location usage*; weatherproof)	
Vibrations As per IEC 60068-2-6	10–58 Hz ± 0.075 mm	58–150 Hz 9.81 m/s ²
Shock As per IEC 60068-2-27	150 m/s ²	
Free fall In transport packaging	≤ 1.0 m	
Ambient temperature Without derating Non-condensing, no dew-formation	+10–+45 °C The control system is thermally inherently safe. If the heat sink is too high, shutdown occurs with an error message	
Ambient temperature With derating	+45–+60 °C 5 %/K at ST-870 / 871 / 880 / 881 4 %/K at ST-872 / 882 3 %/K at ST-873 / 883	
Maximum installation height Without derating	1,000 m above mean sea level	
Relative humidity	< 80% non-condensing	
Storage temperature	-10–+50 °C	
Protection class	1	
Protection class	IP54 Except port X1	
EMC conformity (Interference suppression)	EN 61800-3-compliant Category C2	

Environmental conditions

* The term **fixed location of usage** refers to use in conjunction with a rail system. The rail system must be designed so that the control system is not subjected to impermissible impacts.

Tab. 23: ST-87x / 88x ambient conditions

13.2 Input data

Power supply

Supply type	3-phase AC port, TT or TN mains with directly earthed star point
Rated input voltage	3 x AC 380 to 480 V (± 10 %)
Rated input frequency	50/60 Hz (± 5 %)

Tab. 24: ST-87x / 88x power supply

	ST-870 ST-880	ST-871 ST-881	ST-872 ST-882	ST-873 ST-883
Rated input current	3.5 A	6.0 A	8.0 A	10.0 A
Short-circuit current (SCCR)	5 kA			
Activation current	≤ 7 A 3 mains periods			
Power consumption Standby	8 W (without external consumers)			
Power loss (typical) Self-heating in still air by 35 K	31 W	31 W	43 W	48 W

Tab. 25: ST-87x / 88x power supply

Half-wave/PCM input

Input voltage range* Depending on hardware configuration	AC 220–277 V ± 10% AC 380–480 V ± 10%
Current consumption typical	3 mA
Input frequency synchronous to the grid	50 / 60 Hz (± 5%)

*Measured against the reference phase of the inputs.

Tab. 26: ST-87x / 88x - Half-wave/PCM input

STB_0005, 7, en_GB

Half-wave/Z-stop

Input voltage range* Depending on hardware configuration	AC 380–480 V ± 10%
Current consumption typical	3 mA
Input frequency synchronous to the grid	50 / 60 Hz (± 5%)

*Measured against the reference phase of the inputs.

Tab. 27: ST-87x / 88x - Half-wave/Z-stop

Digital inputs

Current consumption at 24 V	4.2 mA ± 10%
High level	DC +18 ... +30 V
Low level	DC 0 ... +9 V

Tab. 28: ST-87x / 88x digital inputs

Quadrature inputs

	5 V configured	24 V configured	
	QA / QB	QA / QB	QC
Current consumption	1.0 mA (± 10%)	1.4 mA (± 10%)	4.2 mA (± 10%)
High level	DC +2.3 ... +5.0 V	DC +18 ... +30 V	
Low level	DC 0 ... +0.8 V	DC 0 ... +9 V	

Tab. 29: ST-87x / 88x quadrature inputs

13.3 Output data**General**

	ST-870	ST-871	ST-872	ST-873
	ST-880	ST-881	ST-882	ST-883
Braking and on resistance	100 Ω	100 Ω	100 Ω	100 Ω
	60 W	60 W	200 W	300 W
	Internal	Internal	External	External

Axis data

	ST-870	ST-871	ST-872	ST-873
	ST-880	ST-881	ST-882	ST-883
Rated motor power	0.75 kW	1.5 kW	2.2 kW	3.0 kW
Rated output current	2.5 A	4.2 A	6.0 A	8.0 A

	ST-870 ST-880	ST-871 ST-881	ST-872 ST-882	ST-873 ST-883
Maximum device currents (5s)	5.0 A	8.4 A	12.0 A	12.8 A
Operating mode As per IEC 60034-1	S3 60 % ED	S3 40 % ED		
Output voltage	3 X AC 0V ... U_{Network}			
Output frequency	3 ... 120 Hz			
PMW frequency	16 / 8 kHz (automatic / manually selectable)			
Motor protection	PTC / bi-metal (optional KTY)			
Maximum brake stop current	DC 0.3 A			
Brake control output voltage	DC 0.45 * U_{Network}			

Signal output

Relay contact	Max. permitted voltage 277 V Max. permitted load current 25 mA at 85°C (limited by PTC)
Integrated short-circuit protection	Yes
Max. ohmic load	100 kΩ
Max. capacitive load	69 nF

Digital outputs

Version	Short-circuit-proof
Rated output current Maximum	DC 500 mA per digital output
Inductive loads	Yes
High level	DC 24 V (± 5%) RON = 200 mΩ
Low level	< DC 1 V

NOTICE!



Excessive total current of external consumers

The total current of all external 24 V consumers at the digital outputs and the RS485 interface must not exceed 1.0 A.

13.4 Interfaces

RS485	Power supply	DC 24 V ($\pm 5\%$)
	Supply current Maximum	DC 500 mA
	Initial signal level	± 5 V differential
	Input signal level (min.)	± 200 mV differential
	Bus termination	Yes

NOTICE!



Excessive total current of external consumers

The total current of all external 24 V consumers at the digital outputs and the RS485 interface must not exceed 1.0 A.

SPI encoder (optional)

Hardware configuration	5 V supply	24 V supply
Power supply	DC 5 V $\pm 5\%$	DC 24 V $\pm 5\%$
Supply current Maximum	DC 50 mA	DC 50 mA
Interface configuration	5 V unipolar	RS485
Initial signal level	5 V logic	± 5 V differential
Input signal level	Low: 0–1.6 V High: 3.3–5.0 V	Min. ± 200 mV differential
Input current	1.4 mA	RS485 with bus connection

Rail bus

Voltage	AC 24 V modulated
Input signal	Differential
Current consumption	± 5 mA (tolerance: ± 1 mA)

Infra-red

Incidence angle	48°
Control system transmission range	1 m

13.5 Cable lengths and specifications

Connection between:		Cable length	Specification
Vehicle control system	Overhead monorail rails, L1, L2, L3, PE	≤ 2 m	≥ 2.5 mm ² A (AWG 14)

Overhead monorail rail, S1, S2, M		
Overhead monorail rail, Bus A, Bus B		
Brake resistor	≤ 1 m	≥ 1.5 mm ² (AWG 16)
Sensors	≤ 5 m	≥ 0.35 mm ² (AWG 22)
RS-485	≤ 5 m	≥ 0.35 mm ² ^B (AWG 22)
Motor	≤ 3 m	↪ Chapter 'EMC installation notes' on page 48

^A recommended, ^B shielded


13.6 Approvals and standards


Conformity

Devices made by Conductix-Wampfler Automation GmbH have been designed to comply with EU directives. Please contact Conductix-Wampfler Automation GmbH if you wish to obtain a copy of the EU Declaration of Conformity.

Certifications

Controllers of the types ST-87x / ST-88x are tested and certified as follows:

Tested according to	EN 61800-5-1:2007/A1:2017
Certificate number	B 063502 0029
Certification body	TÜV Süd Product Service GmbH
Certification mark	

Tested according to	UL 61800-5-1:2012/R:2021-02 CSA C22.2 No. 274:2017
Certificate number	U10 063502 0028
Certification body	TÜV Süd America Inc.
Certification mark	

14 Information and parameter assignment

To better understand the configuration options and effects of parameter and table values, different types of motors and the functioning of frequency converters are briefly explained in this section.

14.1 Three-phase current asynchronous motor

The three-phase asynchronous motor (TPASM) is one of the most important and common electrical drives.

14.1.1 Layout and function

The three-phase current asynchronous motor consists of a fixed stator and the rotation-mounted rotor. Stator and rotor are composed of thin, highly magnetisable electrical steel plates.




Fig. 27: Asynchronous motor with the pole pair number $p = 1$ and 3 phases Source: Wikipedia

Stator

The stator is not the moving part of the motor. It consists of plate packages in which there are coils made from copper wire in staggered arrangement. Each of these coils produces two magnetic poles. If three windings arranged with 120° staggering are integrated into the sheet packages, then this equates to the smallest pole pair number $p = 1$. Accordingly, the number of poles is deduced by $2 \times p$. If you add three more windings, also staggered in 120° arrangement, to a stator, the number of poles doubles.

If the rated frequency and the pole pair number of the motor are known, then the synchronous speed can be calculated (n_0):

$$n_0 = (f \times 60) / p$$

f = Frequency [Hz]

n_0 = Synchronous speed [rpm]

p = Pole pair number

Pole pair (p)	1	2	3	4	6
No. of poles (2X p)	2	4	6	8	12
n_0 [rpm] (50 Hz rated frequency)	3000	1500	1000	750	500
n_0 [rpm] (60 Hz rated frequency)	3600	1800	1200	900	600

Rotor

The rotor is the rotating part of the motor which is attached to the motor shaft. Like the stator, it is composed of grooved, cylindrical steel plate packages with aluminium bars. Since these bars sit like a cage in the rotor package and are connected to form a closed cage at the front by a ring, this is referred to as a 'squirrel-cage rotor' or 'cage rotor'. This is the rotor type used most commonly.

14.1.2 How it works

Motors use the induction principle in reversed order. A force acts on a current-conducting wire in a magnetic field which produces motion.

If the three windings of a three-phase asynchronous motor in a star or delta circuit are connected to a symmetrical three-phase mains supply, three 120°-phase-shifted currents of equal frequency and amplitude flow into the windings of the stator. They form a rotating magnetic field. This magnetic field acts on the rotor and induces a voltage in the wires that effects a current flow due to the short-circuit of the wires. This current generates a magnetic field, which rotates with the mains frequency f or f/p (p = pole pair number). The magnetic field of the stator acts on this magnetic field so that a rotary motion arises.

Idle operation

In idle, the motor current (no-load current) is used solely to magnetise the sheet metal body. The no-load current is approx. 40–50% of the rated motor current. The rotating field generated follows the rotor at almost synchronous speed.

Operating with loads

The rated load reduces the speed of the rotor to the on-load speed. This difference in speed is referred to as 'slip'. When slip increases, the rotor current, and thus the torque, also increase. Since the three-phase current asynchronous motor operates like a transformer, the rotor current on the stator side (secondary side) is transformed. Thus the current taken from the mains and the frequency converter also changes with increasing torque.

Generator operation

In generator operation, the motion energy is transferred to the motor from outside and converted by it into electrical energy. This energy flows back into the intermediate circuit of the frequency converter. This leads to an increase to the intermediate circuit voltage of the frequency converter. Once the intermediate circuit voltage reaches a particular volume, a braking resistor is activated which converts the excess energy into heat.

Operation on the frequency converter (U/f operation)

During U/f operation a frequency converter modifies the motor voltage and the frequency of the motor voltage at a constant ratio. Frequency and voltage are proportional to one another. Due to the inductive behaviour of the motor, this leads to a nearly constant torque across a wide range.




Fig. 28: Ideal voltage/frequency curve

- 1 Field-weakening operation
- M Torque
- f_E Cut-off frequency

This ideal curve shows that the torque remains constant up to the cut-off frequency. If the frequency of the motor voltage reaches the cut-off frequency, the motor voltage has reached its maximum value. If the three-phase current asynchronous motor is operated beyond the cut-off frequency, the magnetisation of the iron core falls and the motor torque drops, too. The motor is in field-weakening range.

At very low frequencies, a voltage proportional to the frequency would lead to a lower torque due to the ohmic resistance of the winding. To compensate for this, a rise in voltage must be set at the bottom frequency range (< 15 Hz). This rise is referred to as $I \times R$ compensation. The illustration below shows the actual U/f curve with a set voltage rise and the resulting torque.




Fig. 29: Real U/f and M/n curves at a frequency of 50 Hz.

- 1 Load balance
- 2 Balance voltage

Operation on the frequency converter (controlled operation)

In controlled operation, the motor is controlled using a vector control. The vector control uses mathematical models for the control of electric motors. The parameters *motor frequency*, *motor current* and *magnetic flow* of the motor are manipulated with suitable control loops with feedback. This method provides much better dynamics, efficiency and torque generation than control using a U/f curve and similar techniques.

The following illustration (Fig. 30) shows the block diagram of a sensor-less vector control. With the vector control, the measured motor currents are split into a flow-forming and current-forming component. These are transferred into a coordinate system which rotates with the frequency of the alternating values (Clarke-Park transformation). If you observe the values within this coordinate system, they lose their sinus-like character. They can be considered equivalent values on which the known processes of the control technology can be used. The flow-forming component (d) is responsible for the magnetic excitation in the motor and thus enables the physical processes which produce the rotary motion in the motor. The active current and thus the torque of the motor are influenced by regulating the torque-forming component (q).



The 8-series frequency converters can regulate the control of the three-phase current asynchronous motors; both sensor-guided and sensor-less.

Block diagram of controlled operation




Fig. 30: Block diagram of controlled operation

14.2 Permanent magnet synchronous motor

The permanent magnet synchronous motor (PMSM) is part of the group of synchronous motors. Synchronous motors are characterised in that their rotors rotate at the same speed as the magnetic field which the stator windings produce.

14.2.1 Layout and function

Like the three-phase current asynchronous motor, the permanent magnet synchronous motor consists of a stationary stator and the rotation-mounted rotor.




Fig. 31: Permanent magnet with the pole pair number $p = 1$ and 3 phases Source: Wikipedia

Stator	The structure of the stator is similar to the structure of an asynchronous motor with distributed windings.
Rotor	The rotor is the rotating part of the motor which is attached to the motor shaft. In permanent magnet synchronous motors, permanent magnets are located on the rotor.

14.2.2 How it works

If the three windings of a permanent magnet synchronous motor are connected to a symmetrical three-phase mains supply, three 120° -phase-shifted currents of equal frequency and amplitude flow into the windings of the stator. They form a rotating magnetic field. This magnetic field also acts on the permanent magnets of the rotor. The poles of the rotor are pulled by the opposing poles of the field of rotation, and the rotor is placed in a rotary movement. In rated operation, a magnetic bonding exists between the rotary field and rotor field which makes the rotor rotate at the same speed as the field of rotation. In other words, it moves in sync with the rotary field. Provided the rotor and the stator field do not have any relative speed to one another (i.e. they are synchronised), a torque (with an average value not equal to zero) can be formed. The angle between the rotor and stator field determines the level of torque.

Idle operation (polar wheel angle = 0°)

If a permanent magnet synchronous motor is operated in idle, then the poles of the rotor are exactly opposite the poles of the rotary field. In idle, there is no offset between the field of rotation and the rotor. The torque of the motor is equal to zero. The tightening force between the rotary field pole and the rotor pole may be at the maximum, but no effective moment arm is produced.

Operation with load (polar wheel angle 0–90°)

With a load the distance between the rotor poles and the rotary field poles increases and the tightening torque between the poles decreases. The rotor stays lags the idle position by the pole wheel angle h , yet it still turns at the rotary field speed. When the distance is increased, the effective moment arm simultaneously becomes greater. At a polar wheel angle of 90°, the torque reaches its maximum, because here the leading opposite pole has a pulling effect and, at the same time, the following pole of the same name has a pushing effect. The maximum value of the torque is referred to as the tilting torque M_K .




Fig. 32: Polar wheel angle

Overload operation (polar wheel angle > 90°)

If the maximum value of the torque is exceeded, the field of rotation and the magnetic field of the stator magnets lose their magnetic bonding. The synchronicity disappears and the motor falls out of step.

If the motor falls out of step, there is different behaviour for U/f operation and controlled operation.

In U/f operation, the motor will always try to synchronise itself; in other words, it makes short jumps in speed and drops back to a standstill if it does not succeed. The current will increase and fluctuate. Faults may be triggered.

In controlled operation, there will be high noise emissions from the current control loop, because the controller cannot re-establish synchronicity. Excess current faults may be triggered.

Operation on the frequency converter

The torque of a PMSM behaves proportionally to the motor current; its speed proportional to the infeed frequency. At a rated torque (1) and speed (2), a particular voltage is required.

If the frequency converter can supply a higher voltage, the speed can be increased further (7). This leads to a higher power at a constant torque. If the voltage has reached an upper limit, the motor crosses over into the field-weakening range (88).

If the motor mechanics and insulation can support the higher speed and the higher voltage, operation in the field-weakening range with series-8 converters is possible. Information on this is in the parameter settings of the relevant control system.




Fig. 33: How it works

- 1 Rated torque
- 2 Rated speed
- 3 In reference to counter EMK
- 4 Critical speed
- 5 Rated power
- 6 Rated speed range
- 7 Above rated speed
- 8 Field weakening

Another option for expanding the speed range is to change the star circuit of a motor into a delta one, providing the motor allows this. Similarly to asynchronous motors, a delta circuit also leads to a higher voltage on the windings since it is not reduced by a factor of 1.73 or $\sqrt{3}$, as is the case with the star circuit.



The 8-series frequency converters can regulate the control of the permanent magnet synchronous motors; both sensor-guided and sensor-less.

14.2.3 Parameters for the settings of the controlled operation

The parameters which have a significant influence on the behaviour of the frequency converter and the motor in uncontrolled operation are:

Drive

M_	Motor - Type
In_	Motor - Rated current
Un_	Motor - Rated voltage

Drive

Cph_	Cos ϕ
Rot_	Motor - Rated speed
Rs_	Motor - Stator resistance
Ls_	Motor - Stator inductance
Imx_	Motor - Maximum current
TIm_	Time until motor current fault is reported
Tra_	Gear ratio
Dia_	Wheel diameter

Motion

Fn_0	Normal movement - Cut-off frequency
IR_0	Normal movement - I×R compensation
Fn_1	Ascent - Cut-off frequency
IR_1	Ascent - I×R compensation factor
Fn_2	Descent - cut-off frequency
IR_2	Descent - I×R compensation factor
Fn_3	Synchronous movement - Cut-off frequency
IR_3	Synchronous movement - I×R compensation factor
Fn_4	Special movement - Cut-off frequency
IR_4	Special movement - I×R compensation factor
IF1	Factor for current value in I/F mode

14.2.4 Parameters for the settings of controlled operation (vector control)

The parameters which have a significant influence on the behaviour of the frequency converter and the motor in controlled operation are:

- All parameters for uncontrolled operation
- Following table

Motion

Kpf_	Flow regulator proportional gain
Tnf_	Flow regulator integral time
KpVK	Speed regulator proportional gain, pre-decimal point
KpNK	Speed regulator proportional gain, post-decimal point
Tnd_	Speed regulator integral time

Motion

Kpi_	Current regulator proportional gain
Tni_	Current regulator integral time

14.3 Brushless DC motors

Despite their name, Brushless DC motors (BLDC) do not belong to DC motors but to the three-phase current synchronous motors.

14.3.1 Layout and function

The structure and function of a BLDC motor is equivalent to a permanent magnet synchronous motor.




Fig. 34: BLDC motor Source: Wikipedia

The rotor follows a magnetic field of rotation. The movement is synchronous with the AC voltage applied to the windings.



The 8-series frequency converters can regulate the control of the BLDC motors; both sensor-guided and sensor-less. For motor commutation they use sinusoidal commutation.

14.4 Frequency converters

When connecting a motor directly to the mains supply, ideal operating conditions arise at the rated operating point. However, a frequency converter guarantees excellent operating conditions across the entire operating range by adapting its output values (voltage, frequency) to the current load conditions.

A frequency converter allows speed and torque to be adjusted to a powered machine and maintained. The basic functions can be summarised as follows:

- Turning and positioning the rotor
- Speed regulation with and without feedback from the three-phase motor
- Torque regulation with and without feedback from the three-phase motor
- Monitoring and signalling operating conditions

14.4.1 Layout and function

The frequency converter converts the sinusoidal AC voltage of the feeding electricity network into an AC voltage of alternating frequency and amplitude. Frequency and amplitude serve as manipulated variables for the connected motors.

Frequency converters with intermediate circuits consist of four main components:

- Rectifier
- Intermediate circuit
- Inverter
- Control circuit




Fig. 35: Block diagram of a frequency converter and intermediate circuit

14.4.2 Rectifier

The supply voltage is a three-phase AC voltage with a fixed frequency (e.g. $3 \times 400 \text{ V} / 50 \text{ Hz}$). The rectifier is connected to this supply voltage and generates a pulsating DC voltage.

14.4.3 Intermediate circuit

The task of the intermediate circuit is to:

- Smoothing the pulsating DC voltage of the rectifier
- Power reserve in case of voltage supply loss

- Energy storage for load surges and generator operation of the motor
- Reducing mains faults

Electrolytic capacitors are used for energy storage. In idle, the intermediate circuit voltage is typically $\sqrt{2} \times \text{mains voltage}$. When a motor is under load, the voltage drops; and in generator mode, the motor feeds electrical power back into the intermediate circuit, whereby voltage increases. Once the voltage reaches a particular threshold, a braking resistor is activated which converts the excess energy into heat. If the voltage continues to increase, the frequency converter shuts down with a fault to prevent destruction.

14.4.4 Inverter

The output voltage and the output frequency are adjusted in the inverter. The inverter has the task of converting the commutated mains voltage back into an alternating value for supply to the motor.

The main components of the inverter are six IGBTs which are arranged in pairs on three branches (U, V, W). They are used to vary the duration of time the intermediate circuit voltage is connected to the motor windings. The frequency also varies through the shifting of positive and negative voltage pulses during the two half periods along the time axis.

As this technology modifies the width of the voltage pulses, this process is referred to as PWM: Pulse-Width Modulation. With PWM technology, the control circuit controls the activation and deactivation of the semiconductor so that the motor voltage course is as sinusoidal as possible across the inductances of the motor. This means the losses in the motor windings are reduced and a gentle motor operation can be reached even at low speeds.




Fig. 36: PWM output voltage

- 1 PWM signal
- 2 Phase voltage (phase star point)
- 3 Chained voltage

14.4.5 Control circuit

The control circuit is the fourth main element of the frequency converter. It generally has four main tasks:

- Controlling the semiconductor in the frequency converter
- Exchanging data with the main CPU
- Measuring, detecting and issuing faults and warnings
- Protective functions for the frequency converter and motor

The software of the frequency converter offers three different types of control:

- U/f curve
- Vector-based control without feedback
- Vector-based control with feedback

14.4.6 ST-87x/88x Current Monitor

The current monitor of the converter is composed of three components.

- 1 - Short circuit monitor with immediate shutdown of the PWM signals.
- 2 - I^2t -monitors for the motor and the frequency converter whose parameters can be assigned separately.
- 3 - Software-based shutdown of the frequency converter if excess current is detected.

14.4.6.1 Hardware short circuit shutdown

The short circuit signal is developed from the hardware. In this process, the three motor phases and the brake resistor are monitored. The short circuit signal is carried on a special hardware unit (trip zones) of the microcontroller. In the microcontroller this signal travels independently of the software to switch off the PWM signals and the brake resistor. The brake is immediately locked and the fault *[F011]* is output.

There is no parameter assignment for the short circuit detection.

As the short circuit signal for low voltages cannot be generated reliably, the frequency converter is immediately shut down at intermediate voltages of below 450 VDC. The PWM signals are switched off and the brake is locked.

14.4.6.2 I^2t -monitor (maximum load integral)

The I^2t -monitor is a monitor of the current energy volume.

As the energy cannot be measured directly, the product is monitored using RMS and time. The product is proportional to the volume of energy.

Calculate I²t limit

There are two current limits:

- `i_cont` – Continuous current limit
- `i_max` – Maximum current limit

In addition to this there is the maximum time "`t_max`" at which "`i_max`" may be present.

From this the I²t limit can be calculated:

$$I^2t_{lim} = (i_{max}^2 - i_{cont}^2) * t_{max}$$

I²t_lim

I²t_lim represents the maximum limit.

It can reach the I²t-value without a fault being triggered.

Running operation

In live operation, the following I²t-values are summed up in every scanning step:

$$I^2t_{current} = I^2t_{current_old} + (i_{eff}^2 - i_{cont}^2) * t_{scan}$$

- `t_scan` - Duration of the scanning step
- `i_eff` - Current RMS

If I²t_current is greater than I²t_lim, a fault is triggered.

The following formula specifies the maximum time in which a special current value can be present before a fault is triggered.

$$t_{fault} = I^2t_{lim} / (i_{eff}^2 - i_{cont}^2)$$

Example

`i_max` = 10 A

`i_cont` = 5 A

`t_max` = 1 s (maximum time for `i_max`)

`i_eff` = 8 A (current motor current)

$$I^2t_{lim} = ((10 \text{ A})^2 - (5 \text{ A})^2) * 1 \text{ s} = 75 \text{ A}^2\text{s}$$

$$t_{fault} = 75 \text{ A}^2\text{s} / ((8 \text{ A})^2 - (5 \text{ A})^2) = 1.92 \text{ s}$$

For `i_eff` = 10 A would result in `t_fault` = `t_max` = 1 s.

14.4.6.2.1 Motor I²t-monitor

The following motor parameters are relevant:

- `[In_]` (nominal motor current)
- `[Imx_]` (maximum current)
- `[TIm_]` (time to excess current)

From this the following values for the I²t monitor are calculated:

$$i_cont = I_{n_} + (I_{mx_} - I_{n_})/2$$

$$i_max = I_{mx_}$$

$$t_max = T_{Im_}$$

In the event of an error, fault [F115] (excess motor current) is output and the drive is powered down to the highest deceleration ramp before stopping.

14.4.6.2.2 Frequency converter I²t-monitor

$$i_cont = i_converter \text{ class}$$

$$i_max = 12.8 \text{ A}$$

$$t_max = 1 \text{ s}$$

In the event of an error, fault [F118] (excess converter current) is output and the drive is powered down to the highest deceleration ramp before stopping.

14.4.6.3 Software-based shutdown in the event of excess current

If the effective current of the converter exceeds 20 A for 100 ms, the converter is powered down to the highest deceleration ramp before stopping with fault [F018] (current).

15 Customer service and addresses

Customer service

Our service team is available to provide technical information.

■ **Conductix-Wampfler Automation - Service**

Phone: +49 331 887344-15 | Fax: +49 331 887344-19

E-mail: service.potsdam@conductix.com



Service forms

Service forms are available for download under www.conductix.com.

Please send completed service forms to service.potsdam@conductix.com.

Further contacts

Conductix-Wampfler Automation GmbH

Handelshof 16 A | 14478 Potsdam | Germany

Phone: +49 331 887344-0 | Fax: +49 331 887344-19

E-mail: info.potsdam@conductix.com | Internet: www.conductix.com

■ **Conductix-Wampfler Automation - Sales**

Phone: +49 331 887344-02 / -04 | Fax: +49 331 887344-19

E-mail: sales.potsdam@conductix.com

■ **Conductix-Wampfler Automation - Service**

Phone: +49 331 887344-15 | Fax: +49 331 887344-19

E-mail: service.potsdam@conductix.com

■ **Conductix-Wampfler Automation - Repairs**

Phone: +49 331 887344-615 | Fax: +49 331 887344-19

E-mail: repair.potsdam@conductix.com

Conductix-Wampfler GmbH

Rheinstrasse 27 + 33 | 79576 Weil am Rhein | Germany

Phone: +49 7621 662-0 | Fax: +49 7621 662-144

E-mail: info.de@conductix.com | Internet: www.conductix.com

For further addresses of sales and service locations, visit:

- www.conductix.com

16 Index

A

Addresses.....	147
Applicable documents.....	10
Attachment bracket.....	40, 41
Automatic mode.....	98

B

B6 rectifier.....	47
Bus communication.....	87

C

Cable routing.....	50
Capacitive load.....	52
Capacitive loads.....	52
Certifications.....	129
Charging/discharging current.....	48
Circuit breakers.....	46
Cleaning.....	118
Compensation.....	29
Configuration switch.....	77, 78
Configuration table.....	80
Conformity.....	129
Cooling.....	34, 35

Current limit

Continuous.....	144
Maximum.....	144

Current monitor.....	143
----------------------	-----

Customer service.....	147
-----------------------	-----

D

Damage in transit.....	29
DC link voltage.....	143
Design.....	27
Dimensions.....	123
Display.....	36
Extended.....	103
Fault indicator.....	103, 111
Infra-red communication.....	103
Standard.....	102
Distance table.....	80, 84

E

Earth.....	50
Electromagnetic interference.....	47
EMC directive.....	48
EMC product standard.....	48
EMC requirements.....	48
EN 61800-5-1.....	23
Environmental conditions.....	124

F

Fault reset.....	114
Faults to be acknowledged.....	113
Fault types.....	113
Fixing.....	37, 39, 40
Functionality.....	25
Fuse types.....	46

G

Grid feed.....	53
----------------	----

H

Heat sink.....	27, 35
Housing.....	27

I

I ² t limit.....	144
I ² t-monitor.....	143, 144, 145
IGBT pulse inverter.....	47
Infra-red reception.....	36
Input data	
Digital inputs.....	126
Half-wave input.....	125, 126
Input data.....	125
Power supply.....	125
Quadrature inputs.....	126
Z-stop.....	126
Installation.....	39, 40
Installation position.....	36
Intended use.....	16

Interface		X16.....	62
Infra-red.....	128	X17.....	63
Rail bus.....	128	X2.....	58
RS485.....	128	X30.....	64
SPI encoder.....	128	Power class.....	25
Intermediate voltage circuit.....	47	Power on Reset.....	115
L		Protective earthing.....	53
Leakage current.....	47, 50	Q	
LEDs.....	100	Qualification.....	18
Line filter.....	47	R	
Line protection types.....	46	Remote control.....	107
M		Residual current.....	46
Mains fuse.....	46	Residual current circuit breaker (RCCD)....	46
Maintenance.....	19, 117	Responsibility of the operator.....	17
Manual mode.....	98	Responsible party	
Manual reset.....	114	Commissioning.....	67
Material.....	123	Electrical installation.....	43
Model name.....	25	Installation.....	31
O		Operation.....	95
Operating temperature.....	34	RMS.....	144
Operation.....	19, 117	S	
Output data		Safe isolation.....	23
Axis data.....	126	Safety	
Brake resistor.....	126	Operation.....	95
Digital outputs.....	127	Safety notes.....	13
On resistance.....	126	Scanning step.....	144
Signal output.....	127	Segment table.....	83
P		Self-acknowledging faults.....	113
Parameter.....	77	Self-reset.....	115
Parameter values.....	70, 76	Short circuit shutdown.....	143
PE connection.....	53, 65	Short circuit signal.....	143
Personnel.....	18	Speed table.....	80, 83
Pin configuration		Start delay.....	73, 99, 102
X1.....	57	Status LEDs.....	100
X10 BLDC motor.....	59	Stop-offset table.....	84
X10 brake resistor.....	60	Storage.....	30
X13.....	60	Switches the control system off.....	99
X14.....	61	Switch on control system.....	73, 98
X15.....	62		

T

Transfer of risk.....	70
Transport.....	29
Trip zones.....	143
Type label.....	26

U

Unrestrained manual mode.....	98
USB connection.....	64

V

Vehicle parameters.....	78
Vehicle tables.....	80, 81, 83, 84, 85

W

Warranty.....	11
Weight.....	124

X

X1.....	56, 57
X10.....	56, 59, 60
X13.....	56, 60
X14.....	56, 61
X15.....	56, 62
X16.....	56, 62
X17.....	56, 63
X2.....	56, 58
X30.....	56, 64